

# momit **SMART** THERMOSTAT

User guide



# Contents

## First connection

1. Welcome to momitST	4
2. Language	4
3. Loading	5
4. User conditions	5
7. Date/time	6
8. Unit of measurement	6
9. User account	7
10. Email	7
11. User password	8
12. Detected networks	8
13. Network name	9
14. DHCP IP - Fixed IP	9
15. Enter password	10
16. Check connection	10
17. momit Designs	12

## Main menu

1. Home	15
2. Main menu	15
a. Raise/lower temperature	16
b. Use	16
c. Calendar	17
c.1 Programming	17
c.2 Holidays	18
d. Set-up	18
d.1 General set-up	19
d.2 Parameters	19
d.2.1 Safety temperature	20
d.2.2 Calibration	20
d.2.3 Hysteresis	20
d.3 Advanced	21
d.3.1 Smart	21
d.3.2 Presence	21
d.3.3 Ambient	21
d.3.4 Standby	22
d.4 Technical	23
d.4.1 Technical information	23
d.4.2 Last connection	23
d.4.3 Network	24
d.4.4 MAC	24
d.4.5 Reset	24
3. Minimum requirements	25

# First connection

The first time you connect your momit Smart Thermostat, a series of screens will appear, which will take you through the initial device set-up.

# 1 Welcome

---



Welcome to momit Smart Thermostat, the intelligent WIFI thermostat.

# 2 Language


---



Start by selecting your desired language, a mandatory step before you can proceed.

# 3 Loading


---



Now the interface set-up will start, a process that takes no more than 3 minutes.

# 4 User conditions

---



You may consult the user conditions on our website [www.greenmomit.com](http://www.greenmomit.com)

You must accept these in order to continue.

# 5 Date/time

---




Select the current date and time to start programming the thermostat.

momit Smart Thermostat will automatically update the time when appropriate.

# 6 Unit of measurement


---



Select the unit of temperature measurement you want to use.

# 7 User account


---



If you have already created an account, select the corresponding field. If, on the other hand, you have not done so, click on 'create account' and follow the steps that appear on the screen.

# 8 Email

---




Enter the email address you want to use to access your momit Smart Thermostat.

# 9

## User password

---




Create a personal password in order to control your thermostat. It must contain at least 6 characters.

# 10

## Detected networks

---




The networks to which the device may be connected appear on the screen. The network name may also be entered manually.

# 11

## Network name

---



Enter the name of the WiFi you want to connect to.

# 12

## DHCP IP - Fixed IP

---




If you select DHCP IP, a dynamic IP will be assigned to the thermostat. Enter the password of the selected WiFi network.

If you want to assign a fixed IP, you must select this option. Then enter the Gateway, the IP you want to assign to the thermostat and the netmask.

# 13

## Enter password




Enter the WiFi network password.


Once 3 minutes of set-up have passed, the results of the user registration and connection process will appear. If successful, you will receive an email in your registered email account to validate your username. Once validated, which takes less than 2 minutes, you may access the application to finish setting up your account data and remotely manage your momit Smart Thermostat.

# 14


## Check connection



In this screen, we receive confirmation as to whether the user registration and internet connection process were performed correctly.




If the error status shown in the image appears on your screen, this means that the thermostat was unable to connect to the server. If it does not switch to the “OK” status after 30 seconds, you must try again to connect to the WiFi.



In this case, you must check whether the WiFi set-up is correct.


# 15 momit Designs



Using the side buttons, you may browse through the designs and select the one you want by clicking in the centre of the screen.

6 display modes:

- |   |          |   |            |
|---|----------|---|------------|
| 1 | Standard | 4 | Simple     |
| 2 | Elegant  | 5 | Retro      |
| 3 | Maya     | 6 | Minimalist |




## Temperature reading

### MAYA

The tens and units are shown in the bottom left. The tens are represented by hollow circles, while the units are represented by solid circles.

Tens  
Units  
Decimals




### MINIMALIST

In this case, 3 bars appear: the middle one represents the units (the highest), the left one represents the tens and the one on the right represents the decimals (smallest).

The solid dots represent each unit and the hollow dot represents the number 5.

Tens  
Units  
Decimals



# Main menu

Once the initial set-up has been completed upon first connecting your momit Smart Thermostat, every subsequent time that the device is turned on, you will be taken directly to the main menu.

# 1 Home


---



Welcome to momit Smart Thermostat, the intelligent WIFI thermostat.

# 2 Main menu

---



The following options appear in the main menu:

- a. RAISE/LOWER TEMPERATURE  
This option will appear if you give the screen a single tap.
- b. USE
- c. CALENDAR
- d. SET-UP
- e. MOMIT DESIGN

a. RAISE/LOWER TEMPERATURE


With a single tap on the screen, the “+” and “-” symbols will appear.

Use these symbols to select the desired temperature, and once selected, click OK.



b. USE

Allows you to select the Heating, A/C or Off function.



## c. CALENDAR


This section shows the calendar programme. The colour red indicates heating, and the blue A/C.

The hours appear at the top and the days on the left.

There are two options in the Calendar:

c.1 PROGRAMMING


c.2 HOLIDAYS



## c.1 PROGRAMMING

To programme the calendar, select the temperature, start time and end time. Then choose the days on which you would like this to repeat.

Once configured, click accept. The above screen shows the new configuration.




## c.2 HOLIDAYS

When a holiday period is configured, momit Smart Thermostat will turn off the air-conditioning systems until the return date.

When in Holidays mode, the following icon will appear in the screen:




By clicking on this, the Holiday Settings screen will open, where you will have the option of editing or disabling the settings.



## d. SET-UP


- d.1 GENERAL SET-UP
- d.2 PARAMETERS
- d.3 ADVANCED
- d.4 TECHNICAL



## d.1 GENERAL SET-UP

Allows you to access:

- Language
- Country
- Postcode
- Date/time
- Email



## d.2 PARAMETERS

d.2.1 Safety temperature

d.2.2 Calibration

d.2.3 °F / °C



## d.2 PARAMETERS

### d.2.1 Safety temperature

In heat status the temperature is between 8° and 30° and in cold status it is between 15° and 40°. If the temperature rises above or falls below these ranges, the thermostat will enter into safety mode, opening or closing the relay to prevent damage to the systems. This mode will start up whenever necessary. When this status is in control, the following icon will appear in the screen:



### d.2.2 Calibration

In the event of any disturbance, such as external heat sources, variations in the temperature measurement may occur. Using this option, we can calibrate the thermostat to counteract this effect.

The calibration may be configured between -9.9° and 9.9°.

### d.2.3 Hysteresis

This term refers to the difference between the current (ambient) temperature and the set target temperature (momit temperature), so that the air-conditioning systems will switch on and off. It is the margin assigned to the momit temperature to stop or start the boiler operating.

Here are two examples on a 0,5° hysteresis.

1. Heating status: the ambient temperature of our home is 22° but we would like to have 21,5°. In this case, the boiler will be turn on until it gets 21° (0,5° less than the target temperature).
2. Cooling status: the ambient temperature of our home is 22° but we would like to have 18°. In this case the A/A will be turn on until it gets 18,5° (0,5° more than the target temperature).

The hysteresis may be between 0.3° and 1.9°.

### d.3 ADVANCED

Allows you to turn the modes on and off:

#### d.3.1 Smart

#### d.3.2 Presence

#### d.3.3 Ambient

#### d.3.4 Standby

##### d.3.1 Smart

Smart mode automatically learns your routines of use, configuring itself based on this data. This mode will operate after 3 manual modifications have been made to an active calendar slot.

For example, if we set the temperature to 21.5° at 19:00 hrs for 3 Mondays in a row, when a calendar slot was active at this time, the latter will be affected by the new modification and the thermostat will configure itself every Monday at the same time.

##### d.3.2 Presence

The Presence mode operates by switching off all the air-conditioning systems when it detects that no one is in the house after a previously defined time period has elapsed.

This mode is active when the following icon appears on the screen:

If you click on this, the Advanced Settings screen will open, where you will have the option of disabling this.



Presence

##### d.3.3 Ambient


If there are any changes to the light intensity (for example, at night-time periods), the Ambient mode will switch off the air-conditioning systems.

This mode is active when the following icon appears on the screen: If you click on this, the Advanced Settings screen will open, where you will have the option of disabling this.



Ambient

If the Ambient, Presence or Holidays modes are in control, you will not have the option of changing the temperature. To do so, you must disable the active mode.



### d.3.4 Standby

After 1 minute of no activity in the thermostat, the Standby mode will turn off the screen and enter into low energy consumption mode.

Other states of momit Smart Thermostat:


---



#### Manual

When this status is in control, a hand will appear on the screen: 

By clicking on this, the thermostat will change from its current status to the previous status (Off or Calendar).



#### Calendario

When a calendar programme is active, this icon will appear on the screen:



Pressing on it you will access the display of temperature change.

If we vary the temperature manually, we will pass to the Manual mode.



#### Off

When the thermostat is Off, the following icon will appear on the screen: 

Pressing on it, we will access Manual mode (if there is no active schedule on the calendar) or Programming (if there is a defined interval).

## d.4 TECHNICAL

Allows you to access:

d.4.1 Technical information

d.4.2 Last connection


d.4.3 Network

d.4.4 MAC


d.4.5 Reset




### d.4.1 Technical information




### d.4.2 Last connection



### d.4.3 Network



### d.4.4 MAC



### d.4.5 Reset



# MINIMUM REQUIREMENTS

---

momit Smart Thermostat allows you to control heating and air-conditioning systems using potential-free relays for a simple two-wire installation. The control circuit of the systems to be managed must not exceed the maximum operating values of the thermostat relays, described below:

- Relays able to operate at 5A with resistive load and 2A with inductive load as a maximum.
- Switching capacity up to 30VDC (direct current) or 250VAC (alternate current) as a maximum.

momit<sup>®</sup>  
Smart technology for everyone

[www.momit.com](http://www.momit.com)