


The solution of exposure


Step1: decompression software program.



Step 2: Copy these two files to TF card.

Step 3: Equipped with the batteries into hunting camera, then toggle switch in the OFF state, and then insert TF card into hunting camera.

Step 4: Press and hold the "up key" of trail camera, and then toggle switch from the OFF state to the SET state, the hunting camera will automatically upgrade. After the upgrade is completed, the hunting camera will be white screen, and then just restart the hunting camera.



Step 5: Check the hunting camera software version number: 31120