

nedis

ALRMGB10WT

VIBRATION ALARM

For use on doors / windows / personal property

Installation

Attach the vibration alarm by removing the tape covering the adhesive on the rear of the unit.

Operation

You will find the high, low and off switch on the side of the unit. When you switch the unit on you will hear a short alarm signal, this is an indication that the alarm is armed. If the unit is disturbed the alarm will sound for approximately 20 seconds and then re-arm.

Batteries

The unit requires 2 x AAA batteries 1.5V, install as per diagram.

