



LCT02 Sweex LAN PC Card Gigabit

Introduction

First of all, many thanks for purchasing this Sweex LAN PC Card Gigabit. This PC Card easily connects your laptop to a fast internet connection.

To ensure this product operates correctly, we advise you to carefully read this manual first. If despite this manual you still experience problems during installation or operation of this product, go to www.sweex.com and look under the heading service & support.

Contents of the box

Prior to installation, check if all required parts are present. The following parts must be present in the box:

- Sweex LAN PC Card Gigabit
- CD-ROM with manual

If one of the above parts is missing, please contact the supplier.

Specifications

- Realtek RTL8169SBL Chipset
- Supports: 10/100/1000 Mbps connection speeds
- Supports: Auto-Negotiation and Next Page option
- Crossover detection and auto-correction
- Supports: Wake-On-LAN and remote wake-up
- Supports: IEEE 802.3X Full Duplex flow control
- Fully compliant with IEEE 802.3, 802.3u and 802.3ab
- Supports IEEE 802.1Q VLAN tagging

Installation Windows 98SE/2000/XP

We advise you to ensure the operating system is up-to-date before starting the installation. This can be easily checked by starting up Internet Explorer and selecting the option "Windows Update" in the "Extra" menu. Note! Prior to inserting the Sweex LAN PC Card Gigabit in the laptop, it is important to install the drivers first.

The same installation procedure applies to all operating systems. Insert the CD-ROM in the CD-ROM player. It will start automatically. From the menu select the 'Driver'. In the event that the autorun menu does not appear, it can also be started manually. In order to do this, open 'My computer' and go to X:\driver\ (X being the letter of your CD-ROM drive). Here the 'Setup.exe' file will be located, double-click this file and follow the instructions.

The installation is all self-evident. Simply click 'Next' and 'Finish'. Finally, select the option to restart the computer. After having restarted the PC, the Sweex LAN PC Card Gigabit can be inserted in the laptop. Windows automatically detects and installs the PC Card. In the event that Windows asks for confirmation of the PC Card, click 'Yes, continue anyway'. Now the hardware has been installed successfully.

LED indicators

The Sweex LAN PC Card Gigabit includes 2 LEDs.

LED indicators	Colour	Status	Meaning
F	Red	On	Connected at 1000 Mbps
		Blinking	Sending/Receiving Data
L	Green	On	Connected at 10/100 Mbps
		Blinking	Sending/Receiving Data

Warranty

All products under the Sweex brand are warranted for a period of three years. We do not grant support or warranties for any software and/or (rechargeable) batteries included. Warranty claims are settled only via the dealer where the product concerned was purchased.

The rightful owner has and retains title to all brand names and related rights mentioned in this manual.