


# MODEL: 332525

## **FEATURES**

- Large easy to read dial
- Constant lighted dial for night viewing
- Lighted "Alarm-On" indicator
- Ascending alarm volume
- Power Supply: AC 220-240V 50Hz



## POWER SUPPLY

• Begin by plugging in the power cord into a standard household outlet. A moving second hand will confirm the clock has power.

#### SETTING THE TIME

• Open the sliding panel on the back of the clock and turn the TIME SET knob until correct time is shown.

#### SETTING THE ALARM

- Open the sliding panel on the back of the clock and turn the ALARM SET knob to the desired wake up time.
- Slide the ALARM ON/OFF switch on the side of the clock to the ON position to turn on the alarm. The alarm will now sound at the time indicated.
- The small red light in the snooze button indicates the alarm is on.

#### USING THE SNOOZE FUNCTION

• When the alarm is sounding, press the SNOOZE button and the alarm will stop and sound again in four minutes.

#### **TO TURN OFF THE ALARM**

• Slide the ALARM ON/OFF switch to the OFF position to deactivate the alarm. If the alarm is not shut off it will sound again 12 hours later.

## **DISPOSAL AT END OF WORKING LIFE:**

Discarded appliances and electronic devices often still contain valuable materials, therefore do not throw them away, instead hand them in to the store where you buy a new appliance or to your local council recycling depot.

In accordance with the waste guidelines for electrical and electronic equipment, this product must be disposed of separately. If you wish to dispose of this product in the future, do NOT discard it with the household waste, but hand it in at your local refuse collection depot.

In compliance with the directives on Waste Electrical and Electronic Equipment, this product must not be discarded with domestic waste but should be disposed of separately for recycling. If you wish to dispose of this product in the future, do NOT throw it away with the household rubbish but hand it in at a specially designated place, such as your municipal domestic chemical waste depot.

Never throw empty batteries away, but deposit them in special battery boxes or hand them in as domestic chemical waste at your municipal depot.

