






KONIG

KNM-TTFM10



TV STAND

ASSEMBLY INSTRUCTIONS



A1x4	A2x3	A3x3	A4x2
A5x3	A6x4	A7x2	A8x2
A9x2	A10x1	A11x1	A12x2
M5x14 (x4) M-A	M6x14 (x4) M-B	M6x30 (x4) M-C	M8x30 (x4) M-D
M8x50 (x4) M-E	(x4) M-F	(x8) M-G	(x8) M-H

