

SETUP CODES FOR TV

A.R.System	1670,1716,1111,1165,1172
Accent	1694,1750,1811
Ace	1628
Action	1750
Acura	1078,1171
Admiral	1492,1669,1750,1768,1801
.....	1803,1804,1000,1042,1115,1150
Adyson	1369,1701
aeeleer	1645,1060,1061
Agashi	1188
AGB	1645,1772
Agef	1063
Agef	1000,1115
Aiko	1622,1626,1645,1691,1749,1750
.....	1061,1171
Aim	1626,1694,1716,1753,1772,1810
.....	1818,1832,1181,1816
Alwa	1171,1598,1833,1158,1213,1256
Akai	1496,1506,1622,1626,1645,1646
.....	1678,1691,1730,1744,1749,1750,1762
.....	1770,1772,1781,1808,1810,1818,1830
.....	1832,1853,1006,1024,1032,1036,1042
.....	1047,1051,1056,1057,1063,1067,1085
.....	1099,1139,1149,1150,1153,1155,1156
.....	1160,1166,1169,1171,1181,1184,1186
.....	1191,1218,1240,1284,1312,1313,1342
.....	1660,1816
Aki	1691
Akib	1015
Akiba	1626,1646,1015,1074,1081,1082
.....	1085,1119,1165,1178,1181,1657
Akira	1694,1739,1855
Akito	1626,1070,1181
Akura	1626,1646,1653,1750,1811,1050
.....	1078,1081,1082,1085,1148,1168,1171
.....	1178,1181,1186,1655
Alaron	1645,1011
Alba	1620,1645,1646,1653,1770,1013
.....	1031,1040,1042,1053,1060,1073
.....	1078,1080,1081,1085,1095,1099,1114
.....	1118,1121,1145,1150,1154,1164,1168
.....	1171,1173,1181,1186,1188,1191,1280
.....	1313,1659
Albiral	1670,1673,1678,1686,1697,1716
.....	1770,1772,1811,1338
Alcatel	1848,1849,1871,1872
Alhori	1691
Altador	1181
Altorgan	1691,1015,1061,1119
Altser	1626
Altstar	1085
Ambassador	1010
Amplivision	1654,1691,1716,1029,1043
.....	1061,1072,1138,1163
Amstrad	1626,1646,1749,1750,1768
.....	1807,1811,1832,1010,1052,1063,1078
.....	1081,1085,1099,1116,1171,1181,1188
.....	1191,1343,1655
Anam	1626,1171
Anam national	1098
Anglo	1811,1171
Anis	1795
Anitech	1626,1678,1746,1750,1772
.....	1037,1078,1082,1085,1171,1178,1181
Ansonic	1626,1026,1029,1068,1078,1085
.....	1131,1135,1138,1168,1171
Antecno	1749
Apollo	1155
arc en ciel	1069,1104,1110
Arc En Ciel	1179,1196,1199,1202
arcam	1060,1061
Ardem	1181,1186
Aristona	1626,1085,1181,1184

SETUP CODES FOR TV

arita	1691,1795,1834,1816
Art Tech	1678
Arthur martin	1654,1150,1163
ASA	1492,1498,1681,1727,1736,1738
.....	1763,1793,1000,1022,1039,1115,1131
.....	1344,1346,1350,1369,1431,1701
Asberg	1626,1678,1746,1771,1037
.....	1068,1161,1181
asora	1078,1171
Astra	1716,1678,1750,1772,1818
Astro Sound	1716,1764,1770
Asuka	1646,1749,1770,1061,1081
Atlantic	1626,1645,1678,1712,1741
.....	1776,1043,1134,1181
Atori	1171
Atoro	1750
Auchan	1654,1150,1163
Audio Sonic	1280
audio ton	1033,1061
AudioSonic	1497,1626,1646,1750,1811
.....	1856,1029,1033,1061,1071,1078,1081
.....	1085,1102,1138,1140,1169,1171,1172
.....	1181,1186,1196
Audiostar	1749,1863
Audioton	1033,1061,1691,1750
.....	1138,1140
Aurora	1691,1816
Ausind	1676,1435
Autovox	1490,1685,1689,1691,1709
.....	1726,1727,1741,1742,1836,1000,1037
.....	1039,1040,1044,1055,1061,1115,1145
.....	1341,1344,1349,1351,1352,1415,1416
.....	1441
Awa	1496,1497,1526,1557,1621,1623
.....	1624,1629,1645,1678,1750,1762
.....	1772,1114,1166,1170,1176,1363,1364
.....	1370,1655,1816
Axxent	1171
Baird	1499,1652,1753,1762,1058,1061
.....	1067,1109,1113,1160
Bang&Olufsen	1669,1772,1780,1000
.....	1002,1115
Barco	1669,1673,1693,1715,1722
.....	1057,1705
basic	1078
Basic line	1500,1626,1646,1678,1709
.....	1710,1061,1074,1079,1081,1082,1085
.....	1120,1165,1168,1171,1172,1178,1181
.....	1184,1188
Baur	1626,1693,1694,1709,1725,1729
.....	1730,1732,1739,1750,1772,1798,1864
.....	1035,1046,1051,1055,1085,1088,1093
.....	1094,1142,1143,1149,1152,1181,1183
Bazin	1688,1691,1698,1061
BEKO	1563,1678,1745,1788,1856,1029
.....	1033,1085,1138,1140,1164,1166,1169
.....	1181,1186,1188,1244
Beon	1626,1031,1073,1085,1164,1181
Berthen	1168
best	1029,1030,1071,1162,1656
bestar	1029,1079,1085,1138,1172
.....	1181,1286
Bestar-Daewoo	1172
Blazet	1688
Bifonic	1691
Bigston	1750,1811,1816
binatone	1061
Black Diamond	1188
Black Panther	1161
Black Star	1145
blacktron	1178
Blackway	1178
BEKO VIVAX	1144

SETUP CODES FOR TV

Blaupunkt	1568,1569,1570,1571,1573
.....	1578,1729,1730,1737,1743,1779,1781
.....	1821,1843,1024,1035,1114,1133,1142
.....	1143,1165,1214,1245,1247,1347,1354
.....	1355,1357,1391
Blausonic	1691
blue sky	1074,1081,1082,1085,1165
.....	1168,1169,1173,1178,1181,1184
.....	1657,1659,1186,1188,1286
.....	1626,1634,1646,1653,1678
blue star	1082,1178,1770
bondstec	1040,1145
boots	1061,1700,1171
Bpl	1497,1499,1500,1626
.....	1082,1085,1178,1181,1363
brandt	1066,1069,1102,1104,1107
.....	1110,1179,1196,1197,1199
.....	1200,1201,1202,1204,1320
brandt electronic	1104,1199,1202
brandt Electronique	1199,1202
Brinkmann	1626,1031,1073,1085
.....	1140,1164,1168,1181
Brionvega	1492,1501,1502
.....	1537,1538,1594
.....	1626,1669,1678,1717,1753,1768
.....	1785,1803,1822,1836,1837,1841
.....	1000,1052,1115,1210,1441,1705
Britannia	1645,1678,1691,1802,1060,1061
Bruns	1495,1669,1697,1725
.....	1761,1000,1115
Bsr	1688,1724,1747,1807,1838
.....	1015,1057,1119,1150,1353,1356,1358
BTC	1646,1081
Bush	1149,1693,1744,1770
.....	1015,1046,1051,1057,1061,1070
.....	1078,1079,1080,1081,1082,1085
.....	1095,1099,1114,1118,1119,1121
.....	1152,1168,1171,1172,1173,1178
.....	1181,1184,1186,1188,1191,1193
.....	1272,1280,1283,1313,1335,1336
Bush(UK)	1626,1646,1653,1359,1659
Cabletime	1162,1583,1584,1588
Capsonic	1811
Carad	1626,1632,1021,1124,1168,1188
Carena	1626,1074,1085,1165,1181,1657
carivale	1005
carrefour	1085,1095,1114
Cascade	1626,1078,1085,1171,1181
Casio	1626,1678,1181
Catha	1626
cathay	1085,1181
caton	1081
CCE	1626,1085,1181
centrum	1188
Centurion	1626,1085,1181
Century	1492,1669,1686
.....	1000,1040,1115,1145,1157,1482,1483
CGE	1678,1686,1688,1696,1744,1745
.....	1746,1750,1770,1771,1776,1801
.....	1865,1029,1031,1037,1040,1057
.....	1073,1138,1145,1164,1430
CGM	1749,1750,1788,1811,1856,1248
Chaparral	1553
Cherokee	1922
Cie	1749,1750,1816
Cimline	1646,1078,1081,1171
city	1078,1171
Clarivox	1503,1504,1669,1670,1716
.....	1720,1721,1761,1772,1068
.....	1085,1181,1338
Clatronc	1620,1626,1646,1029,1037
.....	1040,1043,1061,1068,1078,1081
.....	1085,1099,1138,1145,1161,1171

SETUP CODES FOR TV

.....	1181,1186,1191,1286,1287
Clayton	1678,1188
Codiam	1475
Compucon	1750,1772
Concorde	1750,1171
Condor	1626,1645,1678
.....	1745,1746,1750,1753,1771,1776
.....	1029,1040,1043,1068,1078,1082
.....	1085,1138,1145,1164,1171,1178,1181
Conic	1818
Conrowa	1907
Contec	1645,1691,1743,1747,1750
.....	1787,1060,1078,1095,1114
.....	1811,1171,1181,1353,1370
Continental	1873,1273
continental edison	1066,1069
.....	1080,1102,1104,1110,1173,1179
.....	1196,1197,1199,1202,1648,1659
Cosmel	1750,1852
.....	1071,1085,1162,1171,1181
Crosley	1492,1568,1669,1672,1696
.....	1746,1773,1000,1037,1045,1057
.....	1115,1145,1151,1361,1362,1482
Crown	1620,1626,1678,1746
.....	1749,1750,1771
Cymatic	1772,1773,1788,1856,1017,1029
.....	1030,1031,1033,1037,1050,1073
.....	1078,1085,1120,1138,1140,1148
.....	1164,1166,1169,1171,1173,1181
.....	1186,1243,1263,1314,1656,1659
Crystal	1678,1053,1154
Cs Electronics	17261749,1040
.....	1060,1081,1145
Cs-electronic	1645,1646
CIC	1040,1145
Ctc clatronc	1678,1686,1697,1745
.....	1746,1749,1770,1771
.....	1775,1811,1433
Curtis	1772
curtis mathes	1091
Cybertron	1646,1081
Cymatic	1670,1691,1770
Daewoo	1505,1546,1626,1645,1646
.....	1686,1691,1749,1750,1772,1810
.....	1823,1884,1886,1061,1078,1079
.....	1081,1085,1087,1171,1172,1174
.....	1175,1181,1184,1189,1232,1233
.....	1131,1269,1271,1284,1286,1816
Dainichi	1645,1646,1060,1081
Dansai	1622,1626,1645,1811,1818
.....	1006,1060,1085,1095,1114,1171,1181
Dansette	1655
dantax	1033,1169,1186
Daul	1286,1331
Dawa	1626,1678,1772,1811
dayton	1078,1171
daytron	1626,1079,1171,1172,1181
De graaf	1693,1056,1156
Decca	1670,1690,1691,1739,1672
.....	1772,1796,1059,1061,1063
.....	1181,1067,1070,1085,1160,1239
Decca(UK)	1595,1626,1339,1341
.....	1363,1365,1368
Deccacolor	1285,1293,1294,1294
Deitron	1626
Denko	1811
Denon	1861
Denver	1750,1085,1181
Desmet	1626,1670,1678,1750
.....	1776,1078,1085,1115,1171,1181
Diamant	1626,1085,1181
Diamond	1750
digatron	1181

SETUP CODES FOR TV	
Digiline	1626, 1132, 1168
Digiline	1626, 1132, 1168
Dixi	1626, 1750, 1078, 1085, 1115, 1171, 1181
Domeos	1678, 1862, 1168
Domah	1678
Doric	1672
Drean	1626
DSE	1363, 1364, 1370
DTS	1171
Dual	1592, 1595, 1626, 1652, 1678
	1691, 1709, 1717, 1723, 1744, 1750
	1768, 1770, 1772, 1864, 1025, 1040
	1055, 1057, 1061, 1085, 1111, 1134
	1181, 1189, 1203
dual tec	1061, 1341, 1348, 1356, 1366
Dumont	1492, 1669, 1678, 1697
	1736, 1738, 1746, 1753, 1633
	1771, 1793, 1000, 1039, 1045
	1068, 1115, 1151, 1161
Dux	1626, 1181
D-Vision	1181
Dynamic	1750
Dynatron	1626, 1181
Dynasty	1678
Edison-Minerva	1173
Elbe	1508, 1626, 1632, 1646, 1670
	1691, 1716, 1728, 1743, 1768, 1770, 1785
	1801, 1804, 1895, 1018, 1025, 1026
	1061, 1062, 1063, 1122, 1124
	1134, 1135, 1157, 1338
Elbit	1678
Electro tech	1750
elekt	1178
Elektronska	1670
Electronis	1678, 1688, 1850
Elg	1626, 1181
Elin	1626, 1645, 1678, 1691, 1725
	1738, 1750, 1808, 1022, 1046, 1051
	1056, 1078, 1085, 1131, 1149
	1152, 1171, 1181, 1660
Elife	1626, 1646, 1043, 1081, 1445
Elman	1697, 1770, 1807, 1068
	1161, 1356, 1366
Ela	1645, 1053, 1078, 1154, 1171
emco	1040, 1145
Emerson	1492, 1626, 1669, 1677, 1678
	1686, 1697, 1746, 1753, 1770, 1772
	1776, 1788, 1811, 1000, 1011, 1040
	1051, 1082, 1085, 1099, 1115, 1116
	1138, 1140, 1145, 1149, 1175, 1178
	1181, 1186, 1191, 1483
emperor	1082, 1178
Engel	1761, 1770
envision	1005
Eres	1626, 1085, 1181
ESC	1626, 1181
Etron	1626, 1750, 1770, 1832
	1854, 1150, 1171
Eurocom	1770
Euromann	1626, 1645, 1691, 1772
	1773, 1138, 1181, 1656
Euromann	1030, 1085
Europa	1626, 1085, 1181
Europhon	1626, 1670, 1686, 1691, 1697
	1341, 1770, 1826, 1061, 1063, 1068, 1154
	1161, 1337, 1356, 1366, 1367, 1483
Expert	1654, 1712, 1134, 1150, 1163
Exquisit	1626, 1085, 1145, 1181
Fagor	1770, 1897
Fagor life	1626
Family	1638
fenn	1078
Fenner	1530, 1577, 1750, 1772, 1079

SETUP CODES FOR TV	
Ferguson	1171, 1172, 1270, 1281, 1370, 1816
	1648, 1650, 1062, 1066, 1085
	1102, 1107, 1109, 1113, 1131, 1449
	1156, 1157, 1176, 1181, 1184, 1196, 1197
	1200, 1201, 1204, 1320, 1321, 1322
	1323, 1334, 1616
Fidellis	1691, 1750, 1772, 1818
Fidelity	1691, 1709, 1733, 1802, 1818
	1042, 1047, 1051, 1055, 1060, 1088
	1099, 1149, 1150, 1181, 1183, 1191
Fidelity(UK)	1566, 1645, 1340, 1371
Filmnet	1539, 1585
Filsai	1691, 1061
Finlandia	1688, 1693, 1027, 1042, 1050
	1056, 1067, 1136, 1148
	1150, 1156, 1160
Finlux	1498, 1506, 1558, 1626, 1670, 1672
	1676, 1697, 1726, 1727, 1736, 1738
	1750, 1762, 1763, 1771, 1793, 1808
	1881, 1000, 1011, 1022, 1023, 1027
	1039, 1045, 1057, 1061, 1063, 1067
	1068, 1085, 1115, 1131, 1132, 1136
	1139, 1141, 1151, 1155, 1160, 1161
	1169, 1181, 1186, 1242, 1344, 1345
	1346, 1350, 1362, 1363, 1366, 1372
	1431
First line	1678, 1686, 1691, 1709, 1744
	1750, 1772, 1810, 1218, 1286
	1626, 1645, 1653, 1015, 1016, 1040
	1055, 1057, 1060, 1061, 1062, 1067
	1079, 1085, 1118, 1119, 1145, 1149
	1152, 1157, 1160, 1168, 1171, 1172
	1181, 1184, 1186, 1188
firstlineer	1078
Fisher	1492, 1504, 1507, 1592, 1669
	1672, 1691, 1709, 1738, 1743, 1753
	1761, 1782, 1784, 1787, 1788, 1791
	1864, 1000, 1022, 1029, 1055, 1057
	1061, 1067, 1095, 1096, 1114, 1115
	1131, 1138, 1160, 1218, 1362, 1373
Flint	1632, 1646, 1678, 1021, 1067
	1074, 1081, 1085, 1124, 1160, 1165
	1181, 1657
Florida	1691
FNR	1068
Formenti	1669, 1672, 1676, 1678, 1688
	1691, 1746, 1770, 1772, 1776
	1807, 1811, 1000, 1043, 1045, 1057
	1060, 1085, 1115, 1151, 1181
Formenti-phoenix	1496, 1645, 1340, 1345
	1362, 1374, 1375
fointech	1145, 1150, 1154, 1171
Fortress	1669, 1115
Fraba	1626, 1029, 1085, 1138, 1181, 1286
Fracarro	1678
Framily	1651
France telecom	1603
Friac	1626, 1029, 1068, 1078, 1087
	1087, 1124, 1138, 1161, 1171, 1181, 1656
Frontech	1750, 1807, 1040
	1061, 1042, 1053, 1078
Fujitsu	1724, 1741, 1749, 1859
	1061, 1067, 1068, 1134, 1160, 1171
Fujitsu General	1171
Furneo	1724
Funai	1497, 1743
	1747, 1750, 1795, 1811, 1863, 1893
	1011, 1015, 1119, 1168, 1314, 1353
Futronic	1811
FUEGO PAOLO	1134
Gaiaxis	1626
Galaxi	1068, 1085, 1181
Galaxis	1678, 1029, 1085, 1138, 1181

SETUP CODES FOR TV	
Galaxy	1691, 1697, 1745, 1746, 1771
Galeria	1750
GBC	1646, 1672, 1686, 1370, 1743, 1749
	1750, 1762, 1770, 1772, 1057, 1078, 1079
	1081, 1171, 1172, 1339, 1341, 1356, 1362
	1363, 1368, 1376, 1377, 1378
GE	1379, 1701, 1701, 1816
	1650, 1866, 1178, 1204
Geant Casino	1163, 1654
Geber	1709, 1710
GEC	1670, 1683, 1688, 1691, 1693
	1704, 1754, 1762, 1007, 1042
	1051, 1058, 1061, 1063, 1067
	1085, 1149, 1150, 1160, 1181
GEC(UK)	1626
Geloso	1486, 1487, 1670, 1672, 1686
	1749, 1750, 1770, 1045, 1057, 1078
	1079, 1151, 1171, 1172, 1341, 1356
	1701, 1362, 1369, 1370, 1376, 1816
Geneesis	1171
General	1648, 1750, 1078, 1658, 1816
general technic	1171
Genexa	1626, 1646, 1042, 1078, 1081
	1150, 1171, 1181, 1655
Giant	1691, 1772, 1789
gibratr	1005
Gitem	1805
GM	1678, 1750, 1811
GMG	1678, 1771, 1811
goldfunk	1168
goldline	1071
Goldmans	1622, 1626, 1650
	1652, 1456, 1659
Goldstar	1490, 1509, 1589, 1615, 1616
	1626, 1645, 1678, 1691, 1693, 1695
	1703, 1723, 1724, 1726, 1750, 1770
	1772, 1779, 1810, 1818, 1834, 1854
	1005, 1038, 1040, 1042, 1051, 1053
	1060, 1061, 1085, 1102, 1144, 1145
	1149, 1150, 1154, 1166, 1169, 1181
	1186, 1196, 1340, 1341, 1380, 1417, 1814
GoldStar/LG	1224, 1284, 1286
	1290, 1300, 1301, 1305
Gooding	1873, 1080, 1173
Goodmans	1678, 1750, 1772, 1869
	1004, 1006, 1011, 1013, 1032, 1061
	1063, 1067, 1078, 1079, 1080, 1081
	1085, 1087, 1087, 1095, 1099, 1107
	1109, 1114, 1118, 1139, 1160, 1168
	1171, 1172, 1173, 1174, 1175, 1181
	1184, 1186, 1188, 1191, 1200, 1201
	1240, 1274, 1284, 1286, 1287, 1288
	1507, 1510, 1638, 1320, 1816
Gorenje	1507, 1510, 1678, 1745, 1773
	1788, 1029, 1030, 1138, 1656
GPM	1646, 1749, 1750, 1081
Gradiente	1626, 1829, 1834, 1009, 1064
Graetz	1626, 1042, 1045, 1051, 1058
	1120, 1149, 1150, 1151, 1173, 1191
Granada	1670, 1672, 1673, 1678
	1688, 1691, 1693, 1721, 1743, 1758
	1772, 1781, 1783, 1789, 1802, 1017
	1047, 1048, 1050, 1054, 1059, 1061
	1063, 1067, 1077, 1085, 1097, 1120
	1146, 1148, 1150, 1153, 1155, 1156
	1160, 1163, 1176, 1177, 1181, 1201
Granada(UK)	1626, 1650, 1654, 1339, 1341
	1364, 1378, 1381, 1382, 1383
	1384, 1385, 1386
Grandin	1620, 1626, 1632, 1634, 1646
	1654, 1683, 1713, 1770, 1776, 1021, 1042
	1043, 1074, 1078, 1078, 1082, 1085, 1124
	1150, 1165, 1168, 1169, 1171, 1172

SETUP CODES FOR TV	
	1178, 1181, 1186, 1188, 1657
Great wall	1590, 1795, 1823
Grandier	1772, 1834
Gronic	1691, 1770, 1772
Grundig	1626, 1668, 1721, 1729, 1730
	1731, 1779, 1810, 1839, 1854, 1873
	1889, 1024, 1035, 1037, 1078, 1080
	1085, 1089, 1090, 1114, 1133, 1142
	1143, 1171, 1173, 1181, 1184, 1185
	1242, 1245, 1246, 1249, 1251, 1282
	1340, 1347, 1355, 1357, 1382, 1387
	1388, 1390, 1391, 1393, 1431, 1659
grunpy	1011
GT	1750, 1753, 1771
H-her	1186
Haier	1193
Halifax	1645, 1061
Hampton	1645, 1691, 1060, 1061
Haninex	1749, 1015, 1119
Hanseatic	1595, 1626, 1672, 1678, 1691
	1693, 1694, 1709, 1725, 1729, 1743, 1748
	1776, 1043, 1051, 1053, 1055, 1061
	1078, 1082, 1085, 1089, 1115, 1119
	1149, 1154, 1171, 1174, 1178, 1181
	1184, 1186, 1362, 1364, 1374
	1381, 1389, 1392
HANSOL	1307
Hantarex	1626, 1670, 1678, 1063, 1085
	1157, 1161, 1171, 1181, 1337
Hantor	1626, 1085, 1181
harly davidson	1007, 1011
Harwood	1626, 1004, 1078, 1085
	1171, 1173, 1181, 1655
Hauptauge	1181
Hauptauge	1626, 1363
havermy	1091
HCM	1626, 1646, 1691, 1749, 1750, 1031
	1061, 1073, 1078, 1081, 1082, 1085
	1164, 1171, 1178, 181, 1655
hema	1061, 1078, 1171
Hemmernann	1394
Hemmernann	1709, 1055, 1152
Hexa	1720, 1770
hifivox	1069, 1104, 1110, 1179
	1196, 1199, 1202
Higashi	1691
Hikline	1626
Hikona	1646, 1081
Hiline	1832
Hinari	1626, 1646, 1690, 1750, 1671
	1770, 1818, 1869, 1011, 1013, 1078
	1080, 1081, 1085, 1095, 1114, 1118
	1119, 1121, 1171, 1181, 1370, 1381
	1395, 1396, 1397, 1659
Hisawa	1646, 1654, 1021, 1072, 1074
	1081, 1082, 1124, 1163, 1165
	1178, 1186, 1657
Hisense	1753, 1123
Hisonic	1791
hit	1000, 1115
hitach	1007, 1008, 1012, 1023, 1034
	1034, 1042, 1045, 1046, 1048, 1054, 1056
	1057, 1058, 1061, 1063, 1067, 1069
	1085, 1087, 1087, 1095, 1102
Hitachi	1398, 1399, 1511, 1558, 1559
	1625, 1626, 1652, 1672, 1683
	1688, 1691, 1693, 1703, 1718
	1719, 1743, 1751, 1754, 1759, 1786
	1790, 1806, 1808, 1810, 1818, 1853
	1899, 1900, 1901, 1114, 1171, 1125
	1132, 1139, 1141, 1146, 1150, 1151
	1152, 1156, 1160, 1174, 1176, 1181
	1188, 1189, 1196, 1214, 1215, 1225

SETUP CODES FOR TV

.....	1226,1227,1228,1283,1284,1288
.....	1298,1341,1377,1378,1379,1381
.....	1384,1392,1400,1401,1402,1403
.....	1404,1405,1861
hitachi fujian	1176
Hitsu	1645,1124,1165,1171,1657
HMV	1000,1115
HOHER	1306
Home Electronics	1166
Homophone	1626,1085,1181
Hoshai	1646,1749,1178,1657
Hotel tv	1619
Huanyu	1645,1060,1079,1172
Hygashi	1645
Hyper	1490,1530,1645,1678,1688
.....	1691,1726,1749,1750,1770,1828,1832
.....	1891,1040,1060,1061,1078,1145,1171
.....	1244,1281,1340,1341,1370
hypersonic	1051
Hypson	1626,1654,1678,1678,1811,1811
.....	1072,1074,1082,1085,1163,1165
.....	1168,1169,1178,1181,1186,1188,1657
Iberia	1626,1085,1181
Iberisao	1709,1770
ICE	1626,1645,1646,1749,1832,1060
.....	1061,1081,1089,1099,1191,1313
Ices	1645,1646,1060,1081
IEG	1691
Imperial	1488,1506,1507,1568,1626
.....	1678,1686,1688,1696,1744,1745
.....	1746,1770,1771,1801,1811,1865,1029
.....	1031,1037,1040,1057,1073,1138,1145
.....	1154,1164,1181,1356,1360,1361,1482
Indesit	1740
Indiana	1626,1085,1181
ingelen	1042,1058,1124,1510
.....	1173,1186,1659
ingersol	1078
ingersoll	1171
Inno hit	1512,1626,1646,1670,1672
.....	1678,1686,1691,1695,1749,1750
.....	1762,1818,1832,1038,1061,1063
.....	1067,1078,1144,1145,1160,1161
.....	1171,1178,1337,1341,1368,1380
.....	1397,1483,1283
Inter(1593)	1640
interbuy	1085,1145,1181
Interdiscount	1678,1717,1719,1732,1866
Interfunk	1492,1626,1668,1672,1673
.....	1678,1681,1683,1694,1709,1710
.....	1717,1725,1771,1000,1002,1040
.....	1042,1051,1058,1085,1088,1104
.....	1115,1145,1149,1150,1152,1181
.....	1183,1199,1202,1342,1364,1377,1382
.....	1383,1389,1406,1407,1408,1410,1412
internal	1085,1181
Intervision	1626,1646,1678,1686
.....	1691,1697,1726,1770,1033,1040
.....	1053,1061,1068,1074,1080,1081
.....	1082,1085,1140,1145,1154,1161
.....	1165,1171,1173,1178,1181
.....	1657,1659,1814,1815
IR	1000,1003,1004,1006,1007,1012
.....	1013,1014,1015,1020,1022,1023,1024
.....	1026,1029,1035,1037,1038,1039,1040
.....	1041,1042,1043,1046,1047,1048,1049
.....	1050,1051,1057,1058,1060,1061,1062
.....	1063,1066,1067,1068,1069,1077,1079
.....	1085,1088,1089,1091,1092,1093,1094
.....	1095,1097,1101,1102,1104,1109,1113
.....	1114,1115,1117,1118,1119,1131,1132
.....	1133,1135,1138,1142,1143,1144,1145
.....	1146,1148,1149,1150,1152,1153,1157

SETUP CODES FOR TV

.....	1160,1161,1170,1172,1176,1177,1181
.....	1183,1196,1197,1199
Iradio	1490,1599,1626,1646,1676
.....	1678,1695,1721,1726,1749,1750
.....	1753,1770,1811,1818,1832,1874
.....	1038,1040,1081,1099,1144,1145
.....	1171,1181,1191,1284,1313,1345
.....	1376,1380,1397
Iskra	1670,1691,1697,1770,1856
Isukai	1626,1646,1074,1081,1082
.....	1085,1165,1178,1181
ITC	1646
ITC	1770,1057
ITL	1750
ITS	1626,1645,1646,1060
.....	1099,1178,1181,1191
ITT	1011,1017,1021,1027,1032,1042
.....	1045,1046,1047,1051,1054,1055,1056
.....	1058,1120,1124,1136,1139,1149,1150
.....	1151,1152,1153,1155,1156
ITT nokia	1120,1124,1136,1139,1149
.....	1150,1151,1152,1153,1154,1155
.....	156,1166,1252,1253,1499,1505
.....	1513,1514,1632,1342,1369,1370
.....	1377,1378,1382,1386,1406,1407
.....	1408,1409,1411,1413,1600,1668
.....	1672,1678,1683,1688,1693,1709
.....	1710,1725,1745,1750,1753,1770
.....	1771,1793,1798,1802,1808,1853
.....	1863,1881,1816
ITV	1626,1085,1145,1172,1181
Janco	1586,1587
Jean	1114
JEC	1622
Jet Point	1678,1813
Jinlipu	1750
JMB	1174,1184
Jubilee	1184
JVC	1515,1516,1646,1717,1733,1743
.....	1827,1829,1832,1031,1064,1065,1073
.....	1075,1081,1095,1099,1112,1114,1164
.....	1166,1191,1205,1264,1268,1313,1332
.....	1333,1414,1456
Kaisui	1500,1626,1645,1646,1678,1691
.....	1749,1750,1823,1832,1863,1895
.....	1060,1061,1074,1078,1081,1082
.....	1085,1165,1171,1178,1181,1657
Kamar	1791
Kambrook	1678,1691,1811,1814
.....	1645,1060
Kapsch	1672,1678,1691,1693,1716
.....	1750,1788,1826,1022,1042
.....	1051,1058,1131,1149,1150
Karcher	1496,1500,1512,1626,1632
.....	1021,1030,1068,1082,1124
.....	1178,1186,1656
kasul	1082
kathrein	1089,1184
kawa	1191
KB Aristocrat	1042,1150,1151
Kendo	1626,1632,1686,1691,1697
.....	1750,1768,1768,1785,1785,1803
.....	1013,1021,1040,1052,1068,1085
.....	1118,1119,1124,1145,1161,1181
.....	1216,1286,1483,1701
Kennedy	1672,1717,1723,1724,1741
.....	1742,1768,1785,1801,1018,1057
.....	1122,1150,1362,1415,1416
kenwood	1005
Kerion	1772
Kic	1691
Kingsely	1645
Kingley	1060

SETUP CODES FOR TV

Kiata	1811
Kiton	1168,1181,1283
Kliff	1691
Kiyogin	1678
Klarmax	1670,1673,1691,1716,1770
Kneissel	1626,1632,1728,1761,1787
.....	1801,1895,1018,1021,1025,1026
.....	1062,1079,1085,1122,1124,1134
.....	1135,1157,1172,1181,1184
Koenig	1672,1776
Koertling	1669,1678,1704,1776,1788
Kolster	1626,1085,1145,1152,1161
Konig	1364
Konka	1626,1646,1909,1910,1911
.....	1912,1914,1915,1916,1918,1919
.....	1081,1099,1164,1181
.....	1185,1186,1191
kontakt	1173,1659
Korpel	1626,1085,1181
Korling	1492,1494,1000,1030
.....	1043,1115,1374,1656
Kosmos	1626,1085
Katron	1795,1811,1655
kayoda	1078,1171
KOPERNIKUS	1115
KOPERNIKUS VIVAX	1167
kraking	1062,1157
Kronne	1691
KTV	1005,1061
kuba	1152
Kuba electronic	1864
Kunya	1717
kyoshu	1164,1655
Kyoto	1670,1691,1716,1770,1042,1150
L&S Electronic	1186
la sat	1033,1140
Lavis	1670
layco	1015,1067,1085
leader	1171
Leccion	1626,1633
Lenco	1520,1575,1576,1577,1626
.....	1022,1172,1181,1370,1376
Lenoir	1678,1691,1709,1750,1171,1341
lesa	1145
Leyco	1620,1626,1678,1747,1762
.....	1807,1811,1119,1160,1181
LG	1010,1626,1645,1144,1145,1150,1154
.....	1140,1178,1169,1181,1184,1186,1193,1196
liesenk&ter	1085
Liesenkotter	1626,1678,1085,1181
Liesensn&Tter	1181
Life	1750
Lifetec	1626,1646,1653,1079,1081
.....	1085,1168,1171,1172,1181
.....	1186,1188,1189
line	1078
Lloyd's	1672,1691,1721,1750
.....	1795,1171
LME	1154
Loewa opta	1492,1493,1526,1550
.....	1579,1626,1389,1418
loewe	1000,1003,1026,1059,1085
.....	1088,1115,1135,1138,1181
.....	1183,1284,1290,1291,1302,1304
Loewe opta	1670,1680,1681
.....	1694,1738,1739
Logik	1690,1733,1734,1092
.....	1170,1191,1365
Logix	1653,1168
Luma	1626,1693,1723,1724,1741
.....	1768,1772,1785,1810,1025,1052
.....	1134,1369,1419,1701,1816
Lumatron	1626,1061,1134,1150,1181

SETUP CODES FOR TV

Lux May	1626,1171,1181
Luxor	1499,1514,1668,1672,1688
.....	1691,1693,1695,1703,1725,1753
.....	1769,1793,1805,1808,1038,1042,1046
.....	1048,1049,1051,1056,1139,1144
.....	1146,1149,1150,1152,1155,1156
.....	1188,1242,1255,1342,1382,1384,1392
.....	1405,1420,1421,1422,1423,1424,1660
Melectronic	1022,1023,1027,1032,1034
.....	1034,1040,1042,1060,1061,1066
.....	1078,1079,1085,1088,1102,1131
.....	1132,1136,1139,1141,1145,1150
.....	1152,1171,1172,1174,1181,1183,1186
Maaz	1673
Madison	1626,1181
Magnadyne	1486,1487,1492,1669,1670
.....	1686,1697,1709,1750,1770,1771
.....	1000,1040,1045,1055,1057,1063
.....	1068,1115,1145,1151,1161,1337
.....	1356,1362,1366,1394,1484,1701
Magnafon	1645,1670,1672,1676,1678
.....	1691,1697,1736,1826,1037,1060
.....	1063,1068,1113,1161,1337,1340
.....	1345,1366,1367
Magnavox	1626,1011,1095,1114,1710
magnum	1085,1169,1181,1186
Manesth	1622,1626,1710,1748,1776
.....	1006,1013,1015,1043,1061
.....	1085,1118,1119,1181
Manhattan	1626,1653,1678
.....	1168,1181,1188
Marantz	1626,1678,1772,1005,1085
.....	1089,1181,1184,1187,1363,1364
March	1776
marelli	1000,1115
Mark	1626,1645,1856,1085,1169
.....	1171,1712,1181,1186
.....	1222,1286,1314
Mastui	1208,1209,1218,1223
.....	1229,1245,1249,1263,1273
Masuda	1646,1171
Matsui	1519,1620,1622,1626,1650
.....	1672,1690,1691,1693,1709,1750
.....	1770,1795,1799,1807,1838,1006
.....	1010,1013,1015,1024,1042,1055
.....	1061,1063,1067,1070,1074,1078
.....	1080,1085,1092,1095,1099,1107
.....	1114,1116,1118,1119,1121,1133
.....	1150,1154,1160,1165,1170,1171
.....	1173,1181,1184,1186,1188,1191
.....	1200,1341,1343,1365,1378
.....	1424,1657,1659
Matsuka	1691,1795
matsumita	1098
Maxam	1750,1795
Maxowell	1670,1673,1678,1697
Maximal	1770,1395
Mce	1750
McMichael	1007
Mediator	1626,1085,1181
Medion	1626,1653,1085,1168,1181
.....	1183,1184,1186,1188,1189,1193,1286
Megas	1632,1021,1124
MEL	1188
Melectronic	1592,1626,1645,1652
Melvox	1654,1072,1163
memorex	1078,1171,1188
Memphis	1852,1071,1171
Mercury	1626,1171,1181
metronic	1204
Metz	1492,1517,1520,1681,1699,1729
.....	1730,1779,1820,1821,1000,1001,1023
.....	1028,1035,1085,1115,1137,1142,1143

SETUP CODES FOR TV

.....	1168, 1181, 1185, 1206, 1355, 1390
.....	1426, 1427, 1428, 1700
MGA	1749, 1005
Micomaxx	1626, 1653
Micommax	1168, 1181, 1188
Micron	1691
minato	1181
minerva	1035, 1080, 1142, 1143, 1173
.....	1176, 1347, 1355, 1382, 1388, 1390, 1659
Minoka	1626, 1050, 1148, 1181, 1655
Mitronic	1818
Mitsubishi	1491, 1492, 1518, 1519, 1626
.....	1681, 1690, 1694, 1730, 1743, 1842, 1860
.....	1000, 1077, 1085, 1088, 1095, 1114, 1115
.....	1142, 1176, 1181, 1183, 1184, 1188, 1275
.....	1276, 1277, 1278, 1381
.....	1389, 1429, 1456, 1816
Mivar	1582, 1645, 1649, 1670, 1671, 1687
.....	1691, 1692, 1695, 1728, 1835, 1026, 1038
.....	1041, 1060, 1063, 1076, 1135, 1138, 1144
.....	1596, 1167, 1337, 1340, 1430, 1431, 1432
Mliver	1248, 1261
monaco	1078, 1171
Morgans	1626
morgans'	1181
motion	1037
motorola	1091
MTC	1645, 1745, 1770, 1029, 1046
.....	1088, 1138, 1152, 1813
MTEC	1070
Mtlogic	1186
Multisystem	1496
multifec	1037, 1059, 1060, 1061
.....	1078, 1140, 1168, 1181, 1188
Multitech	1507, 1509, 1626, 1645, 1653
.....	1670, 1678, 1686, 1691, 1697, 1726, 1745
.....	1750, 1770, 1788, 1140, 1143, 1161
.....	1171, 1181, 1433
multistandard	1161
Murphy	1672, 1042, 1060, 1067, 1150
Murphy(UK)	1645, 1378
Musikland	1646, 1145
myriad	1089, 1184
N.E.I.	1678, 1503, 1626
NAD	1149
Nagel	1817
Nagoya	1688
Naiiko	1626, 1075, 1166, 1181
Nakimura	1626, 1079, 1085
nakio	1032
Namsunc	1750
NAT	1177
National	1781, 1913, 1106, 1177
NEC	1521, 1626, 1690, 1716, 1743, 1750
.....	1823, 1843, 1005, 1009, 1043, 1114, 1127
.....	1165, 1170, 1171, 1172, 1217, 1657, 1816
neckerhmann	1000, 1024, 1029, 1031, 1035
.....	1040, 1043, 1046, 1073, 1085, 1089, 1094
neckerhmann	1507, 1626, 1678, 1681, 1688
.....	1691, 1693, 1729, 1732, 1745, 1772
.....	1776, 1785, 1810, 1115, 1138, 1143
.....	1145, 1152, 1164, 1181, 1184, 1341
.....	1363, 1381, 1392, 1419, 1434, 1701
NEI	1053, 1071, 1085, 1099
.....	1154, 1162, 1181, 1191
nesco	1011, 1040, 1145
Netsat	1626, 1181
network	1071, 1162
Neufunk	1626, 1632, 1085, 1089
.....	1124, 1171, 1181, 1184, 1186
new tech	1061, 1109, 1171, 1181
Newmar	1770
Newtech	1626, 1652

SETUP CODES FOR TV

NEO	1173
NEO VOX	1136
NEO QUART	1139
New-world	1646
nicam	1055
Nicamagic	1645
Nikkai	1622, 1626, 1645, 1646, 1691
.....	1703, 1006, 1060, 1061, 1067, 1071
.....	1078, 1081, 1085, 1095, 1114, 1160
.....	1162, 1171, 1181
Nikko	1852
Noblex	1626, 1743, 1750, 1782
.....	1784, 1791, 1797, 1816
Nobilko	1645, 1676, 1686, 1691, 1697
.....	1736, 1746, 1037, 1060, 1068, 1161
.....	1340, 1345, 1366, 1388, 1483
nogomatic	1069, 1140, 1179
.....	1196, 1199, 1202
Nokia	1635, 1011, 1017, 1021, 1027
.....	1032, 1036, 1042, 1043, 1045, 1046
.....	1047, 1050, 1051, 1054, 1056, 1058
.....	1075, 1079, 1120, 1124, 1136, 1139
.....	1148, 1149, 1150, 1151, 1152, 1153
.....	1155, 1156, 1166, 1172, 1240, 1241
.....	1250, 1252, 1253, 1254, 1255, 1660
Nokia Oceanic	1253, 1254
Nordmend	1522, 1523, 1559, 1626, 1648
.....	1650, 1652, 1402, 1404, 1412, 1435
.....	1436, 1437, 1438, 1439, 1440, 1441, 1471
Nordmende	1672, 1679, 1682, 1714
.....	1715, 1717, 1718, 1719, 1765, 1840, 1866
.....	1066, 1069, 1102, 1104, 1109, 1110
.....	1133, 1179, 1181, 1186, 1196, 1197
.....	1199, 1201, 1202, 1325, 1326, 1327
Norway	1744
normerel	1181
Novatronix	1626, 1678, 1750, 1811
.....	1023, 1085, 1132, 1172, 1181, 1816
Oceanic	1672, 1683, 1688, 1693, 1708
.....	1710, 1713, 1725, 1753, 1805, 1808
.....	1042, 1045, 1051, 1056, 1149, 1150
.....	1151, 1155, 1156, 1163
Oceanicf	1654, 1342, 1377, 1442
.....	1443, 1444
Octal	1691
Ogeneral	1743, 1750, 1859
okana	1029, 1078, 1085, 1138
Orbit	1171, 1181
Okano	1626, 1745, 1750, 1284
Olymoic	1750
Onceas	1686, 1691, 1750, 1341
Onida	1772
onimax	1186
Onwa	1646, 1068, 1081, 1099
.....	1161, 1191, 1313
Opera	1626, 1811
optimus	1098
Orava/off	1678, 1750, 1777
Orbit	1626, 1181
Orient	1678
Orion	1524, 1525, 1526, 1626, 1650
.....	1678, 1688, 1690, 1709, 1747, 1748
.....	1749, 1750, 1751, 1760, 1767, 1769
.....	1774, 1795, 1797, 1807, 1810, 1811
.....	1818, 1823, 1824, 1825, 1838, 1882
.....	1885, 1004, 1010, 1011, 1013, 1015
.....	1016, 1043, 1055, 1063, 1085, 1116
.....	1118, 1119, 1121, 1161, 1170, 1181
.....	1184, 1186, 1211, 1212, 1213, 1288
.....	1343, 1353, 1365, 1394, 1425, 1445
.....	1446, 1655
Orion hungary	1688, 1733, 1772
Online	1626, 1646, 1081, 1085, 1181

SETUP CODES FOR TV

Ormond	1653, 1678, 1716, 1168, 1188
Orsowe	1670, 1063
Osaki	1626, 1646, 1747, 1772, 1811
.....	1061, 1067, 1070, 1079, 1081
.....	1085, 1121, 1160
.....	1172, 1181, 1184, 1655
Osio	1626, 1085, 1114, 1181
Oso	1646, 1081
Osume	1646, 1067, 1081, 1085
.....	1095, 1114, 1160, 1181
otake	1004
Other line	1670
Others	1543, 1544, 1545, 1601, 1602
.....	1626, 1672, 1678, 1691, 1392
.....	1693, 1694, 1709, 1725, 1726, 1729
.....	1730, 1732, 1739, 1743, 1747, 1748
.....	1750, 1752, 1772, 1776, 1781, 1810
.....	1864, 1866, 1013, 1015, 1024, 1035
.....	1040, 1043, 1045, 1046, 1051, 1055
.....	1057, 1061, 1085, 1088, 1089, 1091
.....	1093, 1094, 1095, 1097, 1012, 1109
.....	1114, 1118, 1119, 1142, 1143, 1145
.....	1149, 1151, 1152, 1177, 1181, 1183
.....	1184, 1196, 1362, 1364, 1381, 1389
pacific	1184, 1186, 1188, 1189
Paol	1645, 1060, 1340, 1345
Palladium	1534, 1626, 1745, 1772, 1785
.....	1029, 1031, 1073, 1138, 1145
.....	1152, 1164, 1181, 1186, 1189
Palsonic	1626, 1691, 1749, 1772, 1811
.....	1818, 1164, 1181, 1193, 1655
Panama	1626, 1645, 1686
.....	1772, 1811, 1061, 1145, 1181
Panashiba	1750
Panasonic	1137, 1527, 1549, 1578, 1626
.....	1653, 1672, 1729, 1770, 1778, 1781
.....	1809, 1903, 1904, 1028, 1042, 1045
.....	1051, 1056, 1058, 1063, 1083, 1085
.....	1097, 1098, 1106, 1137, 1149, 1150
.....	1151, 1153, 1156, 1159, 1177, 1181
.....	1257, 1258, 1259, 1260, 1279, 1310
.....	1338, 1340, 1356, 1374, 1377, 1443
.....	1447, 1448, 1449, 1451, 1660
Panavision	1626, 1811, 1085, 1181
Panavox	1672, 1678, 1750
.....	1886, 1887, 1888, 1894
Panorama	1691, 1749, 1750
Panoramic	1717
Pathe	1645, 1654
Pathe cinema	1691, 1699, 1716, 1720
.....	1745, 1770, 1776, 1870, 1042, 1043
.....	1057, 1060, 1062
.....	1150, 1154, 1157, 1163
pathe marconi	1069, 1104, 1110
.....	1179, 1199, 1202
pausa	1078, 1171
PCM	1678
Peony	1789, 1860
Perdio	166, 1042, 1043, 1085
.....	1150, 1160, 1178, 1181
Perfekt	1626, 1181
Pershin	1654, 1720, 1721, 1163
Philco	1488, 1492, 1506, 1507, 1568
.....	1626, 1669, 1672, 1678, 1686, 1688, 1696
.....	1743, 1744, 1745, 1746, 1761, 1770, 1771
.....	1801, 1000, 1029, 1031, 1037, 1040, 1057
.....	1073, 1085, 1115, 1138, 1145, 1164
.....	1181, 1356, 1360, 1361, 1362
Phillex	1566, 1047, 1153
Phillips	1492, 1528, 1529, 1530, 1531
.....	1560, 1567, 1579, 1603, 1626, 1652
.....	1669, 1673, 1674, 1675, 1678, 1681
.....	1691, 1707, 1719, 1729, 1772, 1810

SETUP CODES FOR TV

.....	1857, 1862, 1864, 1868, 1000, 1007
.....	1035, 1079, 1084, 1085, 1086, 1089
.....	1109, 1115, 1143, 1149, 1157, 1171
.....	1172, 1180, 1181, 1182, 1184, 1227
.....	1229, 1251, 1284, 1288, 1292, 1295
.....	1296, 1297, 1298, 1299, 1300, 1301
.....	1302, 1316, 1340, 1363, 1364, 1383
.....	1410, 1450, 1452
Phoenix	1626, 1645, 1000, 1033, 1043
.....	1057, 1060, 1115, 1140, 1181, 1284
Phonola	1512, 1645, 1000, 1060
.....	1085, 1115, 1181, 1286, 1288
Phonotrend	1626
pilot	1005
Pilot(14994y)	1644
Pilot(p15077y)	1636
Pilot(p1631)	1639
Pilot(p3033)	1642
Pilot(p4005)	1641
Pilot(p567)	1643
Pioneer	1580, 1626, 1652, 1678, 1719
.....	1725, 1846, 1847, 1033, 1042, 1051
.....	1066, 1085, 1102, 1140, 1149, 1150
.....	1181, 1183, 1196, 1197, 1221, 1337
.....	1364, 1404
pionier	1138, 1140, 1149, 1181, 1196
Plantron	1626, 1750, 1078, 1171, 1181
playsonic	1061, 1120, 1169, 1181, 1186
Polestar	1551
policom	1199, 1202
poppy	1171
Portland	1678, 1079, 1172
powerpoint	1173, 1181, 1659
royal lux	1138, 1200
prandoni prince	1051, 1063, 1149, 1345
.....	1369, 1483
pranoni prince	1670, 1672, 1686, 1688, 1701
Praxis	1554
precision	1061
Princess	1750, 1818
prinston	1188
prinz	1055, 1149, 1152, 1160
Profekt	1626
Profex	1725, 1746, 1750, 1037, 1042, 1051
.....	1053, 1078, 1149, 1150, 1171
profil	1078, 1171
Profronic	1626, 1068, 1085, 1161, 1181
Proline	1626, 1824, 1016, 1067, 1160
.....	1174, 1181, 1204, 1661
Prosat	1338
Prosonic	1620, 1626, 1645, 1085
.....	1138, 1168, 1172, 1181, 1186, 1191
Protech	1626, 1653, 1772, 1856, 1031
.....	1040, 1053, 1057, 1061, 1068, 1071
.....	1073, 1078, 1085, 1140, 1145, 1154
.....	1161, 1162, 1164, 1168, 1171, 1181, 1188
Provision	1626, 1673, 1678, 1772, 1810
PYE	1000, 1035, 1085, 1089, 1115, 1143
.....	1152, 1172, 1181, 1184, 1286
pyrni	1171
Quadra	1654
Quadra Vision	1163
Qualcraft	1749, 1811
Quasar	1676, 1697, 1807
.....	1818, 1040, 1145, 1171
Quelle	1490, 1558, 1568, 1569, 1571
.....	1572, 1573, 1626, 1653, 1022, 1035
.....	1039, 1051, 1055, 1057, 1085, 1088
.....	1092, 1093, 1094, 1131, 1142, 1143
.....	1149, 1168, 1170, 1181, 1183, 1341
.....	1342, 1344, 1345, 1346, 1347, 1350
.....	1353, 1363, 1364, 1365, 1382, 1387

SETUP CODES FOR TV

.....	1388,1389,1406,1431
questa	1095,1114
QUADRO	1013,1141
Radialva	1626,1646,1053
.....	1071,1081,1085,1154,1162
Radio	1286
Radiola	1579,1626,1061
.....	1085,1181,1184,1288
radiomarelli	1000,1040,1063
.....	1085,1115,1181
Radionet	1672,1683,1738,1763
RadioShack	1005,1085,1181
Radiotone	1620,1626,1856,1039
.....	1078,1085,1168,1171,1181,1188,1655
rank arena	1095,1114
Rank(UK)	1359
Rank/Rbm	1693,1744
RBM(UK)	1359,1431
Rca	1541,1547,1548,1650,1204,1661
realistic	1005
Recor	1626,1678,1772,1085,1181
rectiligne	1181
Rediffusion	1672,1725,1047,1051,1056
.....	1114,1136,1149,1153,1156
.....	1342,1378,1453,1660
redstar	1085
Reflex	1626,1085,1168,1181,1188
Regente	1750
reoc	1186
Revov	1626,1085,1181
rex	1025,1042,1134,1150,1348
.....	1358,1369,1415,1416,1455
Rff	1856,1000,1067
.....	1115,1160,1181
Rhapsody	1645
R-line	1626,1085,1181
Roadstar	1626,1646,1678,1749,1750
.....	1818,1863,1884,1031,1073,1078
.....	1081,1085,1164,1168,1171,1178
.....	1181,1188,1308,1376
robalton	1000,1115
Robafon electr	1669,1761
rowa	1193
Rowsonic	1691
Royal	1691,1749,1750,1771,1772,1811
Royal-Lux	1655,1656
RTF	1000
SABA	1492,1522,1523,1559,1561
.....	1648,1650,1652,1670,1672,1681
.....	1684,1711,1714,1715,1717,1718
.....	1719,1757,1765,1840,1866,1000
.....	1042,1045,1051,1056,1058,1059
.....	1063,1066,1069,1102,1104,1107
.....	1109,1110,1115,1149,1150,1151
.....	1156,1179,1186,1196,1197,1199
.....	1200,1201,1202,1204,1318,1319
.....	1320,1322,1323,1325,1326,1327
.....	1329,1337,1402,1404,1412,1422
.....	1435,1436,1437,1440,1454,1660,1661
sacccs	1062,1157
Sagem	1632,1895,1021
.....	1074,1124,1165,1657
Saisho	1519,1581,1690,1691,1749
.....	1807,1838,1010,1013,1053,1055
.....	1061,1063,1078,1092,1116,1118
.....	1154,1170,1171,1341,1343
.....	1365,1425,1816
salvoad	1168,1181,1188
sakan	1150
Sakura	1750
Salora	1499,1514,1532,1586
.....	1587,1604,1605,1688,1693,1703
.....	1710,1725,1753,1793,1802,1808

SETUP CODES FOR TV

.....	1853,1881,1038,1042,1046,1048
.....	1050,1051,1056,1057,1063,1139
.....	1144,1146,1148,1149,1150,1152
.....	1156,1240,1342,1384,1385,1392
.....	1403,1405,1406,1413,1419,1423
.....	1434,1660,1701,1924
Sambers	1670,1676,1695,1721,1736
.....	1746,1826,1037,1063,1068,1161
.....	1337,1341,1345,1366,1367,1380
sampo	1005
Samsung	1496,1497,1507,1512,1549
.....	1552,1617,1618,1626,1631,1645
.....	1678,1691,1695,1745,1750,1762
.....	1772,1788,1791,1797,1807,1810
.....	1818,1823,1858,1887,1890,1029
.....	1038,1060,1061,1067,1078,1085
.....	1089,1090,1100,1138,1144,1150
.....	1160,1171,1181,1184,1185,1192
.....	1194,1195,1285,1289,1290,1291
.....	1293,1294,1294,1298,1311,1315
.....	1317,1328,1363,1370,1380,1813
.....	1015,1162,1166
Sandia	1645,1670,1691,1060,1061
Sanryo	1753,1819
Sansui	1626,1678
.....	1750,1893,1085,1181
santon	1171
Sanyo	1499,1504,1507,1519,1532
.....	1542,1626,1645,1669,1672,1690
.....	1691,1738,1743,1750,1753,1758
.....	1761,1762,1782,1784,1787,1788
.....	1790,1798,1879,1921,1017,1022
.....	1029,1055,1060,1061,1067,1077
.....	1092,1095,1096,1114,1120,1131
.....	1138,1160,1170,1176,1218,1330
.....	1350,1368,1381,1411,1456
.....	1457,1458,1459,1460
SBR	1626,1007,1085,1181,1184
schaub lorenz	1045,1051
.....	1058,1140,1149,1151
.....	1156,1166,1172,1186
Schneider	1592,1595,1599,1626,1646
.....	1652,1653,1672,1678,1685,1688,1691
.....	1709,1717,1723,1726,1744,1749,1750
.....	1768,1770,1772,1810,1818,1832,1862
.....	1864,1025,1040,1044,1051,1055,1061
.....	1081,1085,1089,1099,1111,1134,1145
.....	1149,1150,1152,1168,1181,1184,1186
.....	1188,1189,1191,1203,1265,1284,1286
.....	1299,1303,1313,1331,1341,1348,1352
.....	1332,1356,1362,1363,1373,1375
scotland	1042,1150
Scott	1678,1776
sears	1011
seaway	1174
SEG	1645,1653,1678,1686,1691
.....	1697,1746,1770,1810,1037,1052
.....	1057,1061,1068,1078,1085,1095
.....	1114,1152,1161,1168,1171,1174,1181
.....	1188,1433,1659
SEI	1000,1010,1015,1045,1055
.....	1057,1063,1068,1093,1115,1116
.....	1119,1150,1151,1152,1161,1181
SEI-Sinudyne	1085,1115,1119,1151
.....	1161,1181
Seleco	1682,1712,1717,1723,1724
.....	1741,1742,1743,1768,1770,1772
.....	1785,1801,1803,1866,1025,1042
.....	1045,1052,1122,1134,1136,1150
.....	1151,1191,1255,1262,1348
.....	1395,1415,1701
Semp	1830
senccora	1078,1171

SETUP CODES FOR TV

Sentra	1622,1646,1770
.....	1783,1006,1081
Serfino	1632,1021,1060
.....	1074,1124,1165,1657
Sharp	1533,1535,1562,1564,1733
.....	1743,1752,1786,1812,1892,1913
.....	1917,1015,1063,1091,1095,1114
.....	1119,1147,1190,1309,1381
.....	1391,1456,1461
.....	1078,1085,1119,1138,1171,1181
SCHNAIDER	1132
shintoshi	1085,1181
Shivoki	1678,1181
Shoral	1747,1011,1015,1119
Shov	1370
Siam	1626
Siarem	1492,1669,1672,1697,1000
.....	1045,1057,1063,1068,1115
.....	1151,1161,1337,1362,1366
Sicatel	1716,1770,1338
Sice	1730
Sidac	1770
sideatone	1146
Siemens	1568,1570,1571,1573,1626
.....	1729,1730,1779,1784,1818,1024
.....	1035,1045,1085,1133,1142,1143
.....	1151,1181,1245,1246,1347,1569
Siera	1626
Siesta	1591,1138
Silma	1678
Silva	1645,1750,1060,1149,1181
silva schneider	1181
Silver	1497,1626,1749,1811
.....	1011,1051,1095,1114,1149,1169
Singer	1486,1492,1626,1654,1669
.....	1670,1672,1678,1686,1697,1713
.....	1750,1772,1801,1030,1068
.....	1115,1122,1161,1171,1181,1200
.....	1362,1366,1484
sinu	1068
Sinudyne	1492,1529,1626,1669,1672
.....	1678,1697,1709,1747,1748,1749
.....	1760,1768,1785,1807,1810,1824
.....	1825,1000,1010,1013,1015,1045
.....	1055,1057,1063,1068,1093,1115
.....	1116,1118,1119,1149,1150,1151
.....	1152,1161,1181,1255,1284,1343
.....	1353,1362,1363,1366,1394,1446,1462
Sirel	1670
Skantic	1668,1048,1049,1146
Sky	1626,1181
Skysonic	1633
Slava	1691
SLR	1168
smaratag	1173
Salavox	1683,1703,1770,1802,1808
.....	1042,1047,1051,1056,1067,1149
.....	1150,1153,1156,1160,1181,1660
Sonawa	1646
soniko	1181
Sonifron	1691,1017,1029,1120,1138
Sonko	1678,1691,1750,1811
sonneclair	1181
sonoko	1078,1082,1085
.....	1171,1178,1181
Sonolar	1654,1042,1051,1149
.....	1150,1151,1156,1163,1178
Sontec	1678,1726,1745,1015,1029
Sony	1536,1565,1597,1690,1732,1743
.....	1764,1772,1844,1845,1905,1906,1920
.....	1068,1093,1094,1095,1114,1128,1129
.....	1130,1161,1170,1181,1207,1208,1235
.....	1236,1237,1238,1239,1267,1365,1456

SETUP CODES FOR TV

.....	1463,1464,1465,1466,1467
sound & vision	1068,1079
.....	1161,1172,1646
soundesign	1011
Soundmaster	1750
Soundwave	1811,1031,1043,1073
.....	1085,1164,1169,1181
Southern cross	1726
spectra	1171
sangyang	1078
ssangyoung	1171
Standard	1646,1686,1691,1749,1750
.....	1776,1043,1061,1078,1079,1081
.....	1085,1171,1172,1181,1188
Star	1772,1872
Starlife	1750,1057,1171,1181
Stenway	1646,1081,1082,1178
Stern	1712,1717,1723,1724,1741,1768
.....	1785,1803,1025,1042,1134
.....	1150,1415,1701
strato	1085,1171,1181
STV1	1691
STV2	1770
stylandia	1061
Sunkal	1626,1646,1678,1747,1748,1825
.....	1863,1015,1016,1021,1074,1119,1121
.....	1124,1165,1173,1657,1659
Sunstar	1620,1078,1085,1099
.....	1171,1181,1191
Sunwall	1772
sunwood	1085,1181
super tech	1060,1078,1085
.....	1171,1181,1184
Superta	1645
Superta	1670,1770,1063
Supersonic	1694,1753,1795,1832
Superfch	1645,1646
Superfec	1678,1750
Superftech	1286
Supervision	1286
Supra	1678,1750,1834
.....	1078,1171,1816
Supreme	1736
Susumu	1650,1081,1197,1200
sutton	1171
SVA	1185
swissline	1145
Syc line	1750
Sydney	1645,1670
syline	1085,1181
Sylong	1645,1060
T+A	1206
tactus	1070
Tadistar	1771
Tai wah	1555,1556
Talent	1730
Tandberg	1517,1603,1670,1680
.....	1717,1718,1747,1768,1820
.....	1003,1028,1137,1262,1353,1700
Tandy	1646,1688,1693,1713,1042
.....	1061,1067,1081,1091,1150,1160
.....	1194
targa	1645,1691,1693,1754,1007
Tashiko	1042,1050,1060,1061,1095
.....	1114,1148,1150
Tatung	1670,1690,1691,1739,1762
.....	1772,1796,1061,1063,1067,1070
.....	1085,1092,1160,1170
.....	1181,1239,1286,1468
TCM	1186
Teac	1627,1085,1152,1154,1165
.....	1168,1171,1181,1183,1193,1283
Teak	1691,1694

SETUP CODES FOR TV

Team	1749
Tec	1650, 1678, 1686, 1691, 1723, 1744
.....	1750, 1770, 1807, 1025, 1040, 1057
.....	1061, 1071, 1078, 1108, 1134
.....	1145, 1162, 1171, 1181, 1658
tech line	1168, 1181
Techica	1646
Technimagen	1286
Techline	1653
technema	1043
technic	1078
Technica	1078
Technics	1781, 1809, 1098, 1159, 1184
technicSat	1184
Techniland	1678
Technol	1691, 1694, 1750, 1795, 1816
technol ace	1011
Technovision	1600
technimagen	1184
Tedexel	1678, 1750, 1770
.....	1772, 1795, 1855, 1154, 1171
.....	1678, 1770
Teknart	1678, 1750
Tele+1	1585
Teleavia	1523, 1648, 1069, 1103, 1104
.....	1109, 1110, 1179, 1198, 1199, 1202
Telecor	1646, 1134, 1150, 1181
Telefac	1750
Telefunken	1522, 1523, 1568, 1572
.....	1648, 1650, 1652, 1686, 1702
.....	1717, 1719, 1734, 1740, 1756, 1757
.....	1765, 1766, 1773, 1850, 1855, 1866
.....	1867, 1033, 1069, 1085, 1101, 1102
.....	1104, 1105, 1107, 1108, 1109, 1113
.....	1136, 1140, 1181, 1196, 1197, 1198
.....	1199, 1200, 1201, 1202, 1204, 1404
.....	1412, 1435, 1469, 1470, 1472, 1472
.....	1477, 1658, 1661
telefusion	1181
Telegaz	1646, 1085, 1134, 1150, 1181
Telegunken	1318, 1319, 1320
.....	1324, 1325, 1326, 1329
telemeister	1043, 1085
Teleopta	1750
Telepoint	1678
TeleService	1567, 1583, 1851
telesonic	1085, 1181
Teleslar	1750, 1811, 1085, 1181, 1184
TeleTech	1653, 1071, 1078, 1085, 1145
.....	1162, 1168, 1171, 1181, 1188
teleton	1025, 1046, 1061, 1095, 1114, 1152
Televideon	1645, 1672, 1676, 1678, 1688
.....	1691, 1776, 1043, 1057, 1060, 1150
televlew	1181
Televio	1654, 1163
temco	1015, 1119
Tempesf	1691, 1749, 1750, 1171
tennessee	1085, 1181
Tensal	1515, 1646, 1678, 1686, 1691
.....	1697, 1738, 1747, 1749, 1750, 1763
.....	1770, 1772, 1776, 1794, 1818, 1826
.....	1004, 1015, 1022, 1023, 1040, 1043
.....	1061, 1078, 1079, 1081, 1085, 1099
.....	1119, 1131, 1132, 1145, 1169, 1171
.....	1172, 1181, 1191, 1350, 1353, 1370
.....	1374, 1376, 1814, 1816
tenson	1043, 1171
Testa	1716
Tetran	1770
Tevion	1653, 1168, 1181
.....	1186, 1188, 1189
textet	1060, 1078, 1079
.....	1081, 1171, 1172

SETUP CODES FOR TV

...1067, 1070, 1079, 1085, 1087, 1087, 1088	
.....1094, 1107, 1109, 1113, 1114, 1131, 1142	
.....1148, 1149, 1157, 1160, 1181	
.....1183, 1196, 1200, 1284	
Thorn-ferguson	1485, 1489, 1497, 1523
.....1566, 1593, 1650, 1670, 1672	
.....1678, 1683, 1688, 1691, 1694, 1709	
.....1710, 1713, 1716, 1717, 1719, 1721	
.....1725, 1729, 1730, 1732, 1733, 1734	
.....1735, 1738, 1743, 1753, 1755, 1756	
.....1758, 1762, 1763, 1764, 1768, 1770	
.....1772, 1783, 1784, 1789, 1790, 1793	
.....1796, 1798, 1799, 1802, 1810, 1811	
.....1827, 1845, 1866, 1881, 1157, 1338	
.....1472, 1473, 1474, 1477, 1481	
TMK	1010
Tobishi	1691, 1749, 1791, 1795
Tobo	1750
tokai	1042, 1071, 1078, 1085, 1150
.....1160, 1162, 1168, 1171	
.....1172, 1181, 1188	
tokaïdo	1188
Tokyo	1622, 1645, 1006
Tomashi	1646, 1082, 1178
Tomita	1691
Topvision	1770
Toshiba	1622, 1647, 1694, 1743, 1783
.....1795, 1799, 1800, 1811, 1830, 1831	
.....1863, 1878, 1902, 1006, 1014, 1019	
.....1020, 1068, 1095, 1102, 1103, 1114	
.....1123, 1126, 1133, 1159, 1161, 1186	
.....1196, 1198, 1219, 1220, 1230, 1231	
.....1316, 1359, 1381, 1431, 1456, 1475	
.....1476, 1478, 1479	
towada	1057
toyoda	1171
trans continens	1061, 1168, 1181, 1188
.....1670, 1678, 1701	
Transonic	1678, 1772, 1171
.....1181, 1185, 1657	
Transtec	1645
Trevi	1750
Trida	1678, 1716, 1772
trident	1063
Trilux	1678, 1856, 1876
Tristar	1646, 1733, 1081
Triumph	1647, 1736, 1807, 1010
.....1014, 1027, 1063, 1089	
.....1116, 1136, 1184	
Trivision	1750
tsoschi	1082, 1178
TVTEXT	1184
TVTEXT 95	1089
Uher	1592, 1685, 1688, 1697, 1712
.....1741, 1776, 1864, 1031, 1033, 1043	
.....1073, 1079, 1085, 1139, 1140, 1164	
.....1172, 1181, 1348, 1349	
.....1373, 1374, 1375, 1415	
Ultravision	1714, 1716
Ultravox	1492, 1645, 1669, 1672, 1678
.....1686, 1691, 1697, 1772, 1775, 1000	
.....1040, 1047, 1057, 1060, 1068, 1085	
.....1115, 1145, 1161, 1181, 1340, 1362	
.....1419, 1433, 1483, 1701	
unic line	1054, 1085
unic linie	1165, 1181
Unic radio	1670, 1691, 1725, 1770, 1788
Unimor	1678, 1788, 1875
united	1085, 1169, 1181, 1186
universal	1181
Universum	1497, 1558, 1653, 1676, 1678
.....1690, 1691, 1694, 1695, 1709	
.....1721, 1725, 1726, 1727, 1729	

SETUP CODES FOR TV

Thomson	1522, 1523, 1559, 1637, 1648
.....1650, 1652, 1676, 1702, 1714, 1715	
.....1717, 1718, 1765, 1792, 1866, 1873	
.....1880, 1883, 1896, 1923, 1046, 1066	
.....1069, 1085, 1102, 1103, 1104, 1107	
.....1108, 1109, 1110, 1152, 1179, 1181	
.....1196, 1197, 1198, 1199, 1200, 1201	
.....1202, 1204, 1319, 1320, 1323, 1327	
.....1329, 1402, 1404, 1412, 1415, 1435	
.....1437, 1440, 1658, 1661, 1706	
thom	1006, 1020, 1022, 1050, 1051, 1062
.....1730, 1738, 1743, 1747, 1750	
.....1763, 1770, 1772, 1773, 1784	
.....1793, 1808, 1811, 1818, 1853	
.....1877, 1009, 1010, 1015, 1022	
.....1023, 1027, 1029, 1030, 1031	
.....1032, 1034, 1034, 1035, 1037	
.....1038, 1040, 1051, 1052, 1055, 1057, 1061	
.....1071, 1073, 1078, 1085, 1088, 1092, 1093	
.....1094, 1095, 1104, 1114, 1116, 1119, 1131	
.....1132, 1136, 1138, 1139, 1141, 1142, 1143	
.....1144, 1145, 1149, 1155, 1164, 1168, 1170	
.....1171, 1181, 1183, 1188, 1199, 1240, 1286	
.....1431, 1656	
Univox	1669, 1716, 1770, 1772, 1000
.....1042, 1062, 1071, 1085, 1115, 1150	
.....1162, 1181, 1338	
UNITED	1266, 1306
Uranya	1670, 1676, 1678, 1697
.....1750, 1776, 1816	
Utax	1691
Vanguard	1691, 1693, 1750
Vegavox	1506
Venus	1898
Vestel	1744, 1922, 1057, 1061
.....1085, 1168, 1181, 1184, 1188, 1286	
Vestel france	1678, 1744
Vexa	1678, 1691, 1749, 1750, 1171, 1181
vibrant	1070
Viceroy	1691, 1795, 1818
Victor	1717
Videcon	1630, 1370, 1475, 1478
Videologic	1691, 1749, 1060, 1081
Videologique	1645, 1646
Videomac	1691, 1795
videosat	1040, 1145
videosystem	1181
Videotechnic	1645, 1043, 1061
Videoton	1670, 1678, 1688, 1691, 1693
.....1716, 1744, 1769, 1770, 1771, 1774	
.....1810, 1880, 1048, 1053	
Vidion	1750, 1753
VIETA	1234
Vision	1645, 1043, 1061, 1181
Vision 2000	1750
Visiorex	1670
Vistar	1710
vortec	1181
Voxson	1492, 1669, 1676, 1000, 1031
.....1042, 1073, 1115, 1150, 1164, 1369, 1701	
VIVAX	1172
VIVAX VOX	1160
VIVAX WEG	1163
VIVAX PROSUNY	1122
VESTEL	1164
VESTEL VOX	1161
W.W.House	1286
Walkie	1723
Waltham	1648, 1031, 1048, 1053, 1061
.....1073, 1085, 1102, 1103, 1146, 1150	
.....1154, 1164, 1168	
.....1181, 1188, 1196, 1198	
Wamishi	1657

SETUP CODES FOR TV

wards	1011
Watson	1620, 1646, 1653, 1672, 1678
.....1772, 1776, 1807, 1811, 1043, 1078	
.....1081, 1085, 1168, 1171, 1181, 1188	
.....1286, 1287, 1331, 1374	
Wattf radio	1645, 1672, 1691, 1697, 1709
.....1716, 1771, 1826, 1055, 1057, 1060	
.....1068, 1161, 1338, 1340, 1362	
.....1366, 1367, 1394	
wega	1000, 1085, 1095, 1114, 1115, 1181
Wega color	1681, 1456, 1480
Wegavox	1686, 1744, 1750, 1771, 1078
Wel blick	1678, 1776, 1043
wharfedale	1181, 1184
Wharfedale	1633
White Westinghouse	1496, 1645, 1043
.....1060, 1071, 1085, 1162, 1181, 1340, 1374	
Winco	1655
Windsor	1678, 1168, 1188
windstar	1082, 1162, 1178
windy sam	1184
Winston	1678, 1749, 1750
Winternitz	1750, 1828, 1816
World tech	1678
Worldsat	1922
Worldview	1678, 1750, 1772, 1823
xenius	1174
xrypton	1085, 1181
Xsat	1908
Yamaha	1159
Yamishi	1646, 1061, 1074, 1082
.....1165, 1178, 1181	
yokan	1085, 1181
Yoko	1496, 1645, 1646, 1678, 1691
.....1750, 1811, 1017, 1030, 1053, 1061	
.....1078, 1081, 1085, 1120, 1145	
.....1154, 1171, 1181, 1341, 1656	
York	1646, 1749
Yoshita	1772
Yotaka	1772
Zampa	1682
zanella	1157
Zanussi	1741, 1742, 1061, 1415, 1701
Zenith	1540, 1574
zenat	1017, 1120
Zoppas	1701

SETUP CODES FOR SAT

AB	3368
AB Sat	3566,3002,3068
Accent	3368
Ace	3368
ADB	3162
Adel sound	3368
Admiral	3368
Aegir	3346
Agashi	3545
Alkal	3030
Alba	3011,3021,3030,3239
.....	3353,3455,3478,3513,3574,3524
Aldes	3005,3343,3346,3538
.....	3540,3541,3542
Alfa gold	3366,3367
ALL VISION	3190,3191
Allsat	3331,3344,3463,3493
Alsonic	3343,3538
Alphasat	3331,3382
Amstar	3403
Amstrad	3007,3024,3026,3071,3107
.....	3127,3128,3149,3160,3203,3204
.....	3240,3320,3329,3442,3450,3510
.....	3516,3523,3603,3605,3648,3338
Armstrong	3338
Ankaro	3005,3032,3048,3205
.....	3343,3489,3538,3591
Anitron	3021,3353,3497
Apollo	3234
Arcon	3014,3496,3516
Armstrong	3004,3331
Asat	3015,3331
Asiagiant	3330
AST	3009,3444,3520
Aston	3463,3596,3643
Astra	3001,3015,3031,3034,3204
.....	3241,3320,3352,3443,3444
.....	3601,3338
Astro	3010,3026,3033,3474,3482
Astrix	3396,3398,3399,3402
Audio Ton	3012,3344,3353
Aura	3262,3319
Auriga	3495,3540
Avalon	3017
Axis	3013
Barcom	3205,3489
Benjamin	3300
Best	3285,3489
Blaupunkt	3482
Boca	3004,3029,3066,3329,3338
British Sky Broadcasting	3071,3102
Brunor	3490
Bruns	3538
Bskyb	3436,3437
BT	3030,3046,3047
Bush	3458,3478,3513
Bush(UK)	3234
Cabletime	3464,3514,3604
Cambridge	3030,3207
Canal Digital	3073
Canal Satellite	3073,3518,3662
Canal+	3073,3111,3360
CCI	3521
Channel Master	3011,3524
Chaparral	3206,3242,3453
Cherokee	3651,3667,3670,3671,3672
.....	3673,3674,3668,3669,4252
City com	3352,3533,3536
.....	3016,3063,3339
.....	3574,3593,3618
Cmr	3033,3346
CNT	3471
Columbug	3005,3343
Commink	3005,3343

SETUP CODES FOR SAT

Comtec	3343
Condor	3352
Connexion cx	3487,3506,3525
Connexions	3017,3023
Conrad	3039,3352
Contec	3013
Cosat	3344
Crown	3004,3338
Cyrus	3003
Daewoo	3015,3574
D-box	3050,3079,3101
DDC	3011,3524
DGTEC	3196,3197,3198
Digiflora	3481
Direct TV	3000
Disistraf	3493
Disk express	3489,3513
Distratel	3084
Disfrisat	3331
DNT	3017,3023,3241,3260
.....	3262,3319,3331,3500,3003
Donatec	3489
Drake	3208,3277,3278,3279
.....	3327,3451,3539
Dynasat	3323,3324,3536
.....	3547,3548,3601
Echostar	3017,3048,3073,3077,3209
.....	3210,3211,3218,3241,3243,3244
.....	3289,3290,3293,3294,3318,3356
.....	3383,3418,3452,3460,3468,3469
.....	3471,3480,3484,3543
.....	3544,3559,3525
Elg galaxy	3414
Elf	3020
Einhell	3329,3343,3338
Electrosat	3426
Elektra	3346
Elsat	3378,3442
Elta	3012,3331,3344
Elta sat	3463,3497
Emanon	3021
Emme esse	3295,3296,3297
.....	3496,3536,3538,3539,3547,3548
.....	3572,3576,3587,3619,3621,3622
Eurleult	3485,3535
Euro space	3406
Eurodec/Sagem	3550,3551,3552
.....	3553,3554
Europa	3331
Eurosaf	3463,3338
Eurosky	3253,3329,3352,3338
Eurostar	3090,3091,3297,3345,3352
.....	3428,3581
Eutra	3060
Exator	3353
Fagor life	3344
Fairmate	3620
Fait	3536,3525
Fenner	3579,3628,3629
Fidelity	3450
Fimmet	3493
Finlux	3001,3018,3019,3246
.....	3247,3483,3488
FM	3463,3596
Force	3392
Formenti	3454
Fortec star	3290,3364,3365,3402,3406
.....	3407,3408,3409,3410,3412,3413
.....	3415,3422,3423,3432,3434,3435
Foxte	3080
Fracaro	3077,3212,3213,3465,3466
.....	3470,3497,3536,3537,3585
.....	3587,3626,3637,3638

SETUP CODES FOR SAT

Seecom	3021,3051,3258
FTE	3075,3449,3496
.....	3595,3596,3597
Fuba	3017,3019,3020,3021,3245
.....	3460,3471,3482,3485,3489,3497
.....	3498,3512,3523,3525
Funtach	3379,3380
G Sat	3445,3447
Galaxis	3343,3344,3005,3012,3013
.....	3044,3062,3069,3075,3098,3115
.....	3117,3119,3130,3134,3135,3156
.....	3200,3463,3538,3586,3596
Galaxy	3590
Galaxy	3429
Gardiner	3063
Glucar record	3214,3248,3481
GMI	3338
Gold Box	3073,3140,3518
Golden cable	3491
Golding	3036
Goldstar	3522
Granada	3458
Grandin	3070,3328
Grothusen	3522
Grundig	3036,3053,3061,3071,3130
.....	3131,3139,3165,3215,3232,3234
.....	3316,3440,3441
.....	3458,3482,3505,3575,3610,3598
Hanseatic	3348
Hanuri	3346
Heliocom	3352,3496
Hinari	3447,3524
Hirschmann	3017,3018,3026,3027
.....	3060,3083,3163,3247,3482,3488,3517
.....	3521,3660,3661,3662,3664,3665
Hiltachi	3270,3384,3385,3458,3492
Houston	3046,3579
HTS	3383
Hughes	3384,3385
Hurnax	3075,3093,3192,3337
Huth	3004,3005,3008,3012,3014,3058
.....	3253,3311,3343,3344,3352,3538,3338
Hwain	3372
Hypson	3485,3485,3535,3535
Hyundai	3147,3589
Icx international	3249
Ikusi Allsat	3014
Imperial	3478,3513,4252
Interfron	3633,3338
Intervision	3038,3344,3352,3355
inVideo	3077
Italtel	3587
Itc	3574
ITT	3001
ITT-nokai	3216,3217,3250
.....	3444,3458,3460,3478,3488,3492
.....	3495,3503,3518,3530,3531,3558
.....	3568,3574,3615,3616,3631,3573
Jeemon	3218,3463
Jerold	3142,3286,3650
Johansson	3219,3344,3470,3486
JOK	3047,3593
JSR	3012,3218,3463,3596
JVC	3030,3036
Kathrein	3002,3010,3016,3022,3025
.....	3041,3045,3094,3126,3146,3152
.....	3220,3221,3222,3251,3301,3331
.....	3339,3353,3443,3473,3474,3482
.....	3527,3533,3536,3600,3659,3003
KeyWest	3058
Kosmos	3473,3522
KR	3353
KreiselMeyer	3482

SETUP CODES FOR SAT

Kyostar	3021,3353
La sat	3545,3555,3556,3557
.....	3029,3033,3039,3329
.....	3346,3352,3338
Laem sat	3596
Lenco	3015,3021,3255,3258
.....	3312,3313,3314
Lennox	3038
Leon	3331
Lexus	3331
Lifesat	3348
Livesat	3578
Loewa opta	3338
Lofenzen	3352
Luxor	3001,3037,3216,3223,3224
.....	3444,3445,3460,3483,3492
.....	3504,3505
Lyonnaise	3647
M-B-B	3348
M.Net	3489,3569
Macab	3072,3082,3252,3599
Macom	3276
Maestro	3651
Magnavox	3309,3386,3387
Manhattan	3033,3038,3095
.....	3344,3346,3458,3463,3540
Marantz	3331,3493,3003
Maspro	3053,3220,3225,3234
.....	3322,3443,3458,3472,3475,3617
Matav	3473,3491
Matsumi	3036,3129
Max	3352
MAXTRONICS	3194
MB	3348
Mediabox	3518
Mediamark	3004,3338
Mediasat	3073,3518
Mega	3331,3493
Memphis	3013,3453,3456
Metronic	3048,3328,3339
.....	3343,3346,3353,3497,3537
.....	3540,3541,3626,3627,3630,3338
Metz	3482
Micro technal	3521
Micro Technology	3034
MICRONAX	3193
Micronik	3088
Microsat	3430
Mimtec	3609
Mina	3326
Minerva	3036,3215,3232,3316
Misc	3635
Mitsubishi	3321,3482
MON	3024
Morgans	3253,3329,3331,3516
.....	3545,3583,3584,3338
Morgan's	3004,3029,3066,3096
Multi choice	3575,3625
Multi choice	3080
Murato	3522
Myryad	3003
Neohausat	3574
NEC	3254,3310,3325,479,3508,3602
Neckermann	3253
Neosat	3401
Network	3226,3447
Neuhaus	3026,3352
NEWLING	3195
Nextwave	3624
Nikko	3048,3500,3570,3632,3125,3338
Nokia	3001,3018,3037
.....	3050,3054,3065,3079
.....	3089,3101,3103,3104,3105,3122

SETUP CODES FOR SAT

.....3141,3174,3175,3199,3334,3363
Nordmenda3346
Nordmende3011,3607
NITVplus3144
Orbitflex3258
Oceanic3571
Octagon3353,3497
Okano3473,3338
Olympic3538
Optex3463,3470,3485,3532,3533,3574
Orava/off3493
Orbit3526
Orbittech3026
Origo3478
Others3376,3417,3280,3315,3332
.....3333,3335,3336,3340,3341,3342
.....3347,3349,3350,3351,3354,3362
Oxford3464,3579
Pace3049,3056,3059,3071,3076,3085
.....3102,3120,3121,3161,3202,3226
.....3227,3232,3234,3317,3370,3371
.....3446,3447,3454,3458,3477,3495
.....3499,3518,3540,3549,3564,3580
.....3639,3649,3652,3657,3201,3668
Pacific3571
Palcom3228,3471,3511,3512,3606
Palladium3036,3253,3338
Palstat3026,3255,3449
Paltex3512
Panasat3026,3040,3375,3419,3575
Panasonic3071,3167,3305,3388,3663
Panda3352
Pansat3287
Patriot3030,3667
Phantom3579
Philips3000,3006,3036,3047,3053
.....3061,3073,3087,3100,3157,3171
.....3234,3256,3257,3292,3309,3331
.....3339,3353,3359,3386,3387,3397
.....3458,3493,3494,3517,3518,3003
Phoenix3013
Phonotrend3005,3038,3055,3343
Pioneer3073,3306,3518
Piox3035
Polytron3016
Praxis3329,3594,3338
Preisner3029
Premier3358
Primestat3286
Prosat3005,3237,3283,3311
.....3343,3355,3448,3455,3524
Protek3571
Provision3346,3540
PSR3414
PIT telecom3510
Pyxis3067
Quadral3011,3032,342,3363
.....3355,3524
Quadro3582
Quelle3215,3352
Radiola3331,3003
Radix3017,3083,3116,3128,3133,3155
.....3241,3260,3262,3319,3525
Rainbow3353
Rank/Rbm3458
RCA3282,3374,3391
RC-AK3288
Rediffusion3508
RFT3005,3331,3343,3528,3003
Ritar3444,3574
RM3416
Roadstar3574
Roch3485,3535

SETUP CODES FOR SAT

Rover3355
RTG3402
SABA3033,3047,3051,3084,3113,3114
.....3132,3136,3137,3150,3170
.....3184,3346,3352,3458,3513
Sagem3099,3550,3551,3552,3553,3567
Sakura3013,3229,3230,3454,3456
Salora3001,3223,3250,3444,3445
.....3460,3492,3503,3509
.....3558,3615,3616
Samsung3185,3186,3291,3307,3308
.....3357,3473,3516,3517,3520,3586,3433
Sat3520,3529
Sat 1003204,3320
Sat partner3497,3522
Satcom3008,3497,3510,3565,3613
Satec3447,3458
Sateco3258,3463,3497
Satline3355
Satmaster3008,3502
Satpartner3021,3027
.....3033,3051,3346,3353
Satstation3095
Schnacke3353
Schneider3061,3536,3645,3646
Schwaiger3016,3035,3098,3348,3447
Scientific atlanta3284
Sedea3497
Seemann3017,3338,3525
SEG3021,3031,3034,3052,3348,3497
Seleco3344,3497,3574,3587
SET3381,3393,3394,3395
Siemens3215,3482
Signal3288,3406,3411
Silva3522
Sintrack3259
Skardin3377,3378,3608
Skr3574
Sky3071,3074,3085,3102
Sky Master3108,3110,3123,3124
.....3148,3166,3183,3111
Sky network3588,3676
Skydigital3436,3437
Skymaster3005,3032,3042,3048,3081
.....3294,3311,3343,3345,3348,3355
.....3381,3383,3411,3436,3438,3439,3538
Skymax3331
Skyvision3344
SL3329
SM Electronic3048
Sony3071,3106,3145,3159
.....3304,3390,3518,3670
Sstcom3348,3352
Star3291,3302,3358,3402,3424
.....3427,3431
Stella3507
Stream3587
Strong3078,3080,3097,3187,3188
.....3189,3231,3255,3258,3312,3324,3346
.....3353,3420,3421,3424,3449,3518,3537
.....3540,3585,3626
STS3225
STV3245
STV13485
STVI3020
Sumida3338
SUN3009
Sun moon3625,3653
Sun moon star3369
Sunsar3029,3058
Sunstar3329,3338
Super max3402,3404,3405,3406
Supernova3085

SETUP CODES FOR SAT

Supex3414,3418,3425
Tada3373
Tagra3344,3460
Tandberg3493
Tantec3228,3458,3471
Technil and3344,3008
TechniSat3023,3026,3138,3143,3154
.....3177,3178,3241,3260,3261,3262
.....3263,3319,3331,3476,3502
.....3515,3517,3519,3525
Technosat3299,3358,3425,3463,3562
.....3596
Technowelt3352
Teco3015,3338
Tedexel3298
Teknika3303
Telasat3348
Tele+13518
Telecel3353
Telecom/televire3463,3507,3577,3596
Telefac3458
Telefunken3021,3495,3579
Telesa3004,3060,3353,3338
Telemaster3346,3540
Telexmax3264
Telemeister3230,3241,3260
.....3262,3301,3319
Telesat3348
Teleservice3588
Telestar3026
Telesystem3536,3574
Teletech3345
Televex3656,3658,3666
Telewire3344
Thomson3073,3092,3136,3171,3172
.....3173,3181,3182,3352,3446,3447
.....3458,3495,3546,3588,3637,3644
Thoreng3571
Thorn-ferguson3226,3227,3232
.....3233,3234,3265,3317,3446
.....3447,3457,3458,3459,3477
Thundermax3493,3518,3597,3595
Tokai3331
Tonna3008,3046,3344
Tonna el.3654,3636
Toshiba3274,3276,3389
TPS3064,3158,3361,3567,3654
Triad3009
Triasat3019,3026
Triax3501,3502,3614
Trida3520,3521,3522
Tristar3449
Ultravox3463,3596
Unbranded3313
Uniden3057,3067,3235
.....3236,3238,3275,3386
.....3387,3461,3462,3467,3641,3642
Uniersum3036
Unisat3013
United satellite3272,3331,3338
Unitor3489
Universum3352,3482,3534
US electronics3249
V technology3522
Vector3031,3262,3319,3521
Ventana3331,3493,3500,3003
Viewstar3309
Visiosat3463,3470,3563,3592
.....3623,3640
Vortec3021,3291,3357
.....3411,3497,3516,3517
Vortic star3357
Vtech3009,3266,3339,3593,3611

SETUP CODES FOR SAT

Watson3109
Wela3329
Winer3219,3281,3400
Winersat3470
Wintergarten3343
Winternitz3442,3444
Wisi3009,3017,3043,3241,3252,3267
.....3268,3269,3270,3271,3460,3482
.....3520,3526,3560,3561,3634,3525
Woorisat3346
Worldsat3651,3667,3670,3671,3672
.....3673,3674,3668,3668,3669,4252
Xcom Multimedia3086
Xcoeco3655
Xsat3002,3086
Yes3085
Zehnder3033,3035,3063,3112,3118
.....3151,3153,3164,3168,3169,3179
.....3180,3222,3339,3473,3520,3612
Zenith3074,3273,3276,3277,3278,3279
Zinwell3377
Zodica3353
Zwergnase3058,3338