

Codici TV - TV codes

@DIKON	1551,1525		
A.R. SYSTEM	0237,0246,0322,0540,1636,5422		
ACCENT	0322,0176,1637,0540,0131		
ACCUPHASE	0540		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1623,1629,1630,1631,1632,1633,1672,1705		
ACEC (PHILIPS)			
ACER	1363,1480,1585		
ACOUSTIC SOLUTION	5422	ADB	5334
ADMIRAL	0024,0080,0222,0428,0429,0440		
ADYSON	0505,0329,0123		
AEA	0513,0540		
AEG	0043,1423,5422,5481,5609,6157		
AG	0557	AGATH	5468
AGASHI	0322,0236,0513		
	0024,0025,0043,0051,0055,0089,0090,0092,0094,0095,0119,0181,0229,0242,0513,1626		
AGB (SABA)			
AGEF(BRUNS)	0024,0077,0242,0336,0363,1623,1667		
AIKO	0067,0513,1608		
AIM	0237,0329,0352,0354,0508,0513,1302		
AIOSTAY	0136	AIRIS	5965,6165,6166
AIWA	0529,0581,1038		
	0043,0067,0074,0143,0147,0162,0236,0290,0296,0298,0037,0345,0352,0354,0361,0375,0415,0431,0433,0513,0515,0549,0558,1243,1311,1314,1396,1423,1623,1636,1652,1659,1684,5827,5840,5864,5961,5964,6120,6164,6173,6174,6183		
AKAI			
AKARI	1321	AKI	0236,1638
AKIBA	0513,0540	AKIO	1318
AKIRA	0236,0141,0374,1251,1485,1637,5454,5965,6118		
	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300,0322,0329,0352,0409,0415,0418,0447,0471,0472,0513,0555,0557,0588,1009,1251,1368,1422,1425,1623		
AKITA (ORION)			
AKITO	0540,0513		
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557,1423,1608,1678,1681,1694		
AKTRON (TOSHIBA)			
AKURA	0143,0176,0231,0236,0322,0513,0540,5422		
ALBA	0236,0300,0415,0513,1659,5422,5839,5864		
ALBATRON	1378		
ALBIRAL	0025,0125,0236,0237,0322,0513,1174,1639,1659		
ALBRECHT	1586	ALHORI	0067
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557,1423,1608,1678,1681,1694		
ALKOS (TOSHIBA)			
ALL TEL	0550,1451,0145,1383,5821		
ALLORGAN	0067,0108,0391		
ALTEK	1392,1399,1401,1494,1526,1546,5421,5454		
ALTUS	0557,1603	AMIKO	6180
AMBASSADOR	0196	AMPLIVISION	0067,0237
	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410,1415,1423,1425,1469,1559,1638,1639,5338,5415,5422,5437,5481,5851		
AMSTRAD			
ANAM	0513,0540	ANDERSSON	5422
ANEX	1636,1639	ANGLO	0322
ANIS	0322,0336		

ANITECH	0077,0114,0322,0329,0424,0505,0513,0540
ANSONIC	0043,0057,0077,0141,0236,0322,0336,1657,5422
ANTARES	5469,5487 AOC 1540
	0096,0295,0327,0351,0549,1450,1609,1649,1652,1693,1694,
AQP (GRUNDIG)	
ARCAM	0067
ARCELIK	0141,0230,0557
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026
ARCENCIEL(THOMSON)	
ARDEM	0141,0541,0336,0557
ARGENTINA	0568,0569,0570,0572
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705
ARISTONA (PHILIPS)	
ARPHONE (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619
ARTHUR MARTIN (SALORA)	0075,0080,0082,0083,0137,0147,0162,0170,0178,0192,0236,0390,0431,0433,1016,1659
ART-TECH	0424,0513,1638
ASA	0066,0136,0282,0390,0513
AS-BERG	0131,0077,0302,0374,1636,0513
ASORA	0322
	1638,0415,0114,0490,0131,0230,1639,0136,1657,1658,1659,0513,1363,0236,0125,0097,0043,0077,0024,1227,0327,0547,0196,0067,1317,0336
ASTHON (EMERSON)	
ASTRA	0415,0329,0296,0302,0067,0354,1485
ASTRO SOUND	0237,0230
ASUKA	0067,0322,1659
ATAKI	0424 ATEC 1597
	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654
ATLANTIC (FORMENTI)	
AUDIOLA	5491,5868
	0513,0557,0141,0067,0125,0149,1638,0230,0123,0025,1227,0077,1696,0162,0322,0060,0490,0424,0336,0354,0545,0236,0209,1636,0557,1657
AUDIOSONIC	
AUDITON	0114,0067,0125
AUDIOVOX	0572
AURORA	0024,0067,0354
AUSIND	0131,0136,1126
	0043,0108,0123,0131,0136,0391,0552,1124,1126,1367,1423,1653,5422,5449,6120
AUTOVOX	
AUVISAT	1456 AVIOUS 1550
AVERMEDIA	1515
AWA	0149,0067,0354,0184,0540,0513,0236
AXXWNT	0236 AXIL 6163
BAIRD	0375,0378,1668,5481
BANG & OLUFSEN	0024,0398
BARCO	1128,0024,0090
BARCOM	0329 BASTIDE 0067
	0203,1423,0513,0424,0097,0043,0236,0354,0373,0557,0230,0141
BASIC LINE	
BAUER	0069,0114,0236,0275,1302
	0046,0083,0133,0140,0162,0165,0174,0176,0178,0215,0236,0259,0290,0337,0351,0352,0391,0434,0467,0508
BAUR	

BAUR	0528,1352,1632,1637,1652,1656,1676		
BAUMATIC	0322		
BEAUMARK	0547	BAZIN	0067,0441
BEKNTEKNIK	0337,0207,1657		
BEKO	0141,0207,0227,0230,0236,0336,0540,0541,0557,1400,1435,1603,6202		
BELSON	1472	BELSTAR	5422
BENNET	0513,0540	BENQ	1593
BENSTEN	1511,0550,0145,1491		
BEON	0513,0540		
BESTAR	0114,0336,0415,0435,0540,0513,1657		
BIAZET	0052,0236	BIFONIC	0067
BIGSTON	0322,0354	BINATONE	0067
BLACK DIAMOND	0043,0540,5422		
BLACK STRIP	1608	BLACKWAY	0351
BLAUPUNKT	0039,0069,0096,0102,0148,0149,0165,0266,0351,0522,1693,6162,6185		
BLAUSONIC	0067		
BLOOM	0043,1386,1390,1399,1415,1433,5422,5481,5851		
BLUEH	5824	BLUE MEDIA	1590
BLUESKY	0043,0051,0065,0097,0141,0236,0513,0541,0549,0557,1423,1425,1556,1560,1603,1619,5422,5481,5864		
BLUESTAR	1648,1659,5864	BLUETECH	5825
BLUSENS	6118,6171,6172,6173		
BOCA (AMSTRAD)	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410,1415,1423,1425,1469,1559,1638,1639		
BONDSTEC	0125		
BOOTS	0067	BOOTS	0067
BOSCH/BAUER	0069	BOSTON	0067
BOTECH	1575	BPL	0513,0540
BRANDT	0051,1435		
BRANDT ELECTRONIQUE (THOMSON)	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
BRAUN	0067	BRAVO	5456,5493
BRIGMTON	0067,0237		
BRINKMANN	0513,0540		
BRIONVEGA	0295,0247,1367,1124,0222,0024,0428,0223,0440,1181,1622		
BRITANNIA	0067,0192	BROKLINE	1319
BROKSONIC	0236,1323,		
BROTHER	0043,0322	BROWN	1317
BRUNS	0242,0336,1667,0024,0363,0077,1623		
BSR	0300,0158,0329,1659		
BUSH	0097,0052,0083,0043,0236		
CADMOS (DESMET)	0025,0114,0230,0236,0246,0513,1319		
CALIFORNIA (FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
CAMPER	0141,0336,0513,1696		
CANAIS	0042	CANALERA	1507
CANALSANTE (SIDECE)	0230	CANTON	0252
CANDLE (LG)	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,0513,0529,0542,0547,0555,0557,0587,0925,1439,1459,1476,1606,1607,1614,1659,3044,4206,4207		

CAPSONIC	0322,1636	CARAD	0513,0540
CARENA	0236,0540		
CARREFOUR	0513,0540,5338		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
CARYONSE (PHILIPS)	0513,0540		
CASCADE	0513,0540		
CASIO	0409,0540,1611		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341		
CASONIO (OCEANIC)	1529,1535,1536,		
CAT	0513,0540	CBM	1458
CATHAT	0513,0540		
CCE	0513,0540		
CDV	1410,1464,5464,5868,5872,6176		
CELINT	0052	CENTURION	0513,0540
CENTURY	0024,0057,1227		
CEY	1028		
	0057,0102,0131,0227,0298,0473,0374,1636,1638,1650,1659		
CGE	0043,0097,0227,0236,0322,0336,0424,0513,1657,1659		
CGM	0060,0196,0354,0513		
CIE	0115,0230	CINEMA	0043
CIHAN	1324		
CITIZEN	1657		
CLARITRONIC	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667		
CLARIVOX	0540,5449		
CLATRONIC	0043,0230,0513		
CLAYTON	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
COFADEL (THOMSON)	0024	COLUMBIA	0046
COLOR MAT	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300,0322,0329,0352,0409,0415,0418,0447,0471,0472,0513,0555,0557,0588,1009,1251,1368,1422,1425,1623		
COMBITECH (ORION)	0513,0536,1425,1492		
COMET	0415,0431,0513		
COMPUTRON	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,0529,0542,0547,0555,0557,0587,0925,1439,1459,1476,1606,1607,1614,1659,3044,4206,4207		
CONCERTO (LG)	0043,0114,0131,0227,0236,0259,0322,0374,0424,0513,0540		
CONDOR	0431		
CONFORAMA(SONOLOR)	0296,0329		
CONIF	1435		
CONRAC	0043	CONTI M.	0236
CONRAD	0322,0197,0067,0540,0184,0424		
CONTEC	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
CONTIN.EDIS.(THOMSON)	0114,0549,1636,1639		
CONTINENTAL	0490,0513,0540,1636		
COSMEL	0513	CRC	0046
COSMOS	0043,0057,0077,0097,0131,0141,0236,0336,0374,0540,0541,1420,1639,1657,5338,5422,5864		
CROWN			

CROSLEY	0024,0057,0115,0131		
CRYSTAL	0043,0046,0513,0592,1632		
CS ELECTRONICS	0067,0125		
	0057,0067,0077,0114,0131,0170,0227,0230,0236,0322,0374,0415,0424,0513,0557,1423,1603,1636		
CTC CLATRONIC	0024,0043,0067,0077,0097,0114,0125,0131,0136,0196,0230,0236,0327,0336,0415,0490,0513,0547,1227,1317,1363,1638,1639,1657,1658,1659		
CXC(EMERSON)			
CYMATIC	0025,0067,1659		
CYV	0513,0540		
	0060,0067,0209,0236,0352,0354,0361,0375,0502,0513,0545,0554,0557,1390,1412,1449,1450,1453,1601,1644,5450		
DAEWOO			
DAICHI	0209	DAIMOND	1637
DAINICHI	0067		
DALMAN	1453		
DANSAI	0067,0329,0513,1608		
DANTAX	0043,1423		
	0060,0067,0209,0236,0352,0354,0361,0375,0502,0153,0545,0554,0557,1390,1412,1449,1450,1453,1601,1644		
DATRONIC (DAEWOO)	0513		
DAWA			
DAYMATER(MAGNADYNE)	0024,0025,0060,0077,0115,1009,1639,1659		
DAYTEK	0236,0572,1121		
DAYTRON	0513,0540,1318		
	0060,0067,0209,0236,0352,0354,0361,0375,0502,0153,0545,0554,0557,1390,1412,1449,1450,1453,1601,1644		
DAYTRONIC(DAEWOO)			
DCE	0557,1603		
DE GRAAF	0043		
DECCA	0065,0067,0176,0246,0254,0302,0375,0540,0541,1636,0513		
DEITRON	0557		
DELTON			
DEMACOLOR	0236	DENKO	0322
	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
DENTAL(FORMENTI)			
DENVER	0043,1546,1638,5609,6120,6162,6190		
DESMET	0025,0043,0114,0230,0236,0246,0513,1619		
DEWO	1085		
DHS(ASTRA)	0067,0296,0302,0329,0354,0415,1485		
DIADEM	0440	DIAMAT	0513,0540
DIAMOND	0047,0352,0354,1112,1121,1338		
DIBOSS	1516,1517	DICRA	5405,5872,5958,6159
DIGATRON	0513,0540		
DIGIHOME	0557,1435	DIGILINE	0043
DIGITOR	0236,0540,0555		
DIK	0513,0540	DINASTY	0043,0354
DIKOM	5851,5873,5888,5958,5963,5965,6114,6159,6189		
DIKON	1551,5416,5437	DISTAR	50236,1085
DIUNAMAI	1535,1587,5416,5439,5484,5831,5875,5965		
DIXI	0513,0540,1667		
DOMEOS	0236,0434	DMTECH	1489
	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153,0158,0162,0170,0196,0209,0222,0230,0236,0298,0312,0329,0354,0391,0409,0434,0513,0592,1400,1636,1659		
DOMLAND(DUAL-TEC)			
DOMOH	0236,0513,1639		
DORIC	0052	DPM	5446

DTS	0153,0513		
	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153,0158,0162,0170,0196,0209,0222,0230,0236,0298,0312,0329,0354,0391,0409,0434,0513,0592,1400,1636,1659,5422,5449		
DUAL TEC	0024,0066,0077,0115,0374,0131,0136,0236,0282,0390,0513,1619,1636,1639		
DUMONT	1659		
DUNAI	0043,0552,0557		
DURABRND	0540	DYNAMTC	0074
DUX	0209,0236,0352,0554		
D-VISION	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
DYNATRON(PHILIPS)	1394,1398,1399,1484,1525,5481,5819,5823,5871,6187		
EASY LIVING	1346	ECO LINE	0236
ECCO	0067,0236	EDAN LINE	0043,0236
ECHOSTAR	0549		
EDISON	0162,0227,0230,0236,1423,1657		
EI	1394,1398,1399,1484,1525,5481		
EL	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237,0255,0295,0428,0429,0440,0528,0541,1425,1449,1450,1452,1453,1454,1529,1594,1595,1619,1659,5481		
ELBE	0024,0025,0060,0077,0115,1009,1639,1659		
ELCIT(MAGNADYNE)	0424,0322,0354,0046,0513		
ELEKTA	0025,0230	ELEKTRONIKA	0516,1657
ELEKTRONSKA IND.	0043,0230,0336		
ELEMIS	0513,0540		
ELG	0066,0067,0083,0153,0162,0282,0431,0513		
ELIN	0114,0322,0513		
ELITE	0322,0425	ELSA Y	0236
ELLEVISION	0025,0067,0077,0196,1659,1700		
ELMAN	0057,0067,0322,0435,0513	E-MOTION	6185
ELTA	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341		
EMATEC(OCEANIC)	0043,0057,0060,0102,0131,0170,0227,0236,0298,0374,0435,0513,0522,1227,1619,1636,1650,1659		
EMCO(IMPERIAL)	0024,0043,0067,0077,0097,0114,0125,1227,0131,0136,0196,0230,0236,0336,0327,0415,0490,0513,0547,1317,1363,1638,1639,1657,1658,1659		
EMERSON	0230,1611,6163,6181		
ENGEL	0529	EROICA	0329
ENIE	0566,0579,1332		
ENZER	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
ERRES(PHILIPS)	0067,0336,0236,0513,0540		
ESC	0230	ETCO	5338
ESTEL	0384,0415,0513,1063,1082,1648		
ETRON	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237,0255,0295,0428,0429,0440,0528,0541,1425,1449,1450,1452,1453,1454,1529,1594,1595,1619,1659		
EULANDER(ELBE)	0114	EUROCOM	0230
EUMIG	1631,1636,5338		
EUROLINE			

EUROMAN	0067,0322,0336,0513
EUROPA	0513,0540
EUROPHON	0025,0067,0077,0114,0127,0230,0238,0238,1227,1659
EUROSTATUS	0043 EUROVISION 1423
EXCEL	0513,0540 EVELUX 0592 EVERLINE 6186
EXPERT	0153,0204,1654
EXQUISIT	0513,0540 FAGOR 0435,0513
FAMILY LIFE	0513,0540
FELIX	0236,0322,0415
FENNER	0354,0424,0513,0516,1623
FERGUSON(THORN)	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700
FIDELIS	0043,0067,0296
FIDELITY	0067,0176,0329,0391,0415,0513,1713
FILSAI	0067 FINLANDIA 0083
FINLUX	0043,0066,0077,0115,0127,0131,0136,0137,0147,0170,0230,0236,0246,0282,0295,0374,0375,0390,0431,0433,0513,0557,0558,1126,1425,1603,1623,5422,5481
FIRST LINE	0043,0057,0067,0097,0114,0123,0176,0177,0203,0230,0237,0298,0302,0352,0354,0375,0391,0440,0513,0541,0557,1009,1420,1425,1435,1453,1636,1654,1659,5338,5422
FISHER	0363,0133,0066,0123,0314,0115,0197,0149,0184,0290,0024,0391,0373,1131,1657,1658
FLINT	0073,0513,5873,6160 FLORIDA 0067
FORCE	1329,1330 FNR 0077
FORGESTONE(THORN)	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700,
FORMENTI	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654
FORTRESS	0024 FRABA 0236
FRIAC	0077,0513,0540
FRONTECH	0057,0083,0329,0125,1659,1696
FST(DECCA)	0065,0067,0176,0246,0254,0302,0375,0540,0541,1636
FUJI	0424
FUJITECH	0513
FUJITSU	0043,0077,0067,0108,0153,0158,0222,0236,0282,0329,0513,1345,1408
FUMEO	0158
FUNAI	0149,0230,0322,0552,0557,1588,1663,5422,5449,5835
FUSION	0557,1435 FURICHI 0595
FUTURE	0513,0540 FUTRONIC 0322
FUTURETECH(EMERSON)	0024,0043,0067,0077,0097,0114,0125,0131,0136,0196,0230,0236,0327,0336,0415,0490,0513,0547,1227,1317,1363,1638,1639,1657,1658,1659
GALA	0296,0329 GALACTEX 0067,0322
GALANT	0415,0424
GALAXI(FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654
GALAXY	5458,5460
GALAXY-GALAXIS	0057,0067,0227,0236,0374,0409,1636
GBC	0060,0115,0125,0197,0354,0375,0415,0424,0513,1489,1659,5473
GE	0051,0242,0547,1495

	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252, 0431,0433,1626,1654,2356,4340,4341		
GEANTCASINO(OCEANIC)			
GEBER	0162		
GEC	0067,0083,0189,0236,0246,0375,0513,1076,1372,1626,		
GELOSO	0025,0060,0080,0115,0354,1659		
GENERAL	0046,0067,0197,0209,0354,0513,5823		
GENERAL CORPORATION	0043,0067,0108,0153		
GENESIS	0513,0540		
GENERAL TECHNIC	0354		
GENEXXA	0540,0162,0390		
GERICOM	1383		
GIANT	0046,0067,0527		
GITEM	0046,0242,1609,1636		
GM - GMC	0322,0513,1663		
GOLD	1526,5420,5845,5851,5866,5870		
GOLD TOP	0424	GOLDFUNK	0094
GOLDHAND	0067		
GOLDLINE	0073		
	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153, 0158,0170,0227,0277,0230,0236,0275,0329,0352,0384, 0513,0529,0542,0547,0555,0557,0587,0925,1439,1459, 1476,1606,1607,1614,1659,3044,4206,4207		
GOLDSTAR(LG)			
GOLDTECH	0043,0097,0236		
GOLDVISION(SONOKO)	0123,0236,0322,0424,0505,0513,0557,1636		
	0043,0051,0067,0097,0141,0209,0242,0322,0327,0352, 0354,0415,0513,0541,0545,0554,1423,1603,1608,1636, 1659,5422,5481		
GOODMANS			
GORENJE	0051,0236,0516,0592,1296,1423,1657,1658		
GPM	0322,0329	GRADIENTE	0502
	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153, 0162,0192,0236,0252,0290,0322,0327,0374,0390,0391, 0433,0513,1423,1626,1654,1713		
GRAETZ(ITT)			
	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153, 0162,0192,0236,0252,0290,0322,0327,0374,0390,0391, 0433,0513,1423,1626,1654,1713		
GRANADA			
	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230, 0236,0322,0354,0435,0513,0541,0542,1619,1636,1637, 1639,1654		
GRANDEN(FORMENTI)			
	0043,0073,0114,0141,0170,0209,0230,0236,0352,0422, 0424,0541,0557,1383,1412,1425,1453,1548,1549,1564, 1569,1603,1654,5422,5481,5864		
GRANDIN			
GREAT WALL	0322,0490	GRANPRIX	5481
GRENADIER	0230,0513,0547,1174		
GRONIC	0067,0230,0238,1174,1659		
	0096,0295,0327,0351,0549,1491,1450,1609,1649,1652, 1693,1694,5334,5864,6202		
GRUNDIG			
GTRONIC	0236,1084	GUTTA	1084
GTT	0043,0236,0374,0424,1638		
H & B	0043	HADOR	1338
HAIER	0209,5474,5848,6162	HALIFAX	0322
HAMMERSTEIN	0067,0322,0384,0422,1082	HAMPTON	0067,0115
HANNOVER	1420	HANNSPREE	5819,5822,5867,5960
	0025,0067,0114,0162,0195,0209,0230,0236,0296,0336, 0391,0424,0435,0513,0554,0557,1601,1638,1639,1644, 1693		
HANSEATIC			
HANTAREX	0025,0077,0238,1383,1436,1636		

HARWOOD	0513,0540	HARROW	0043
HAUPPAGE	0513,0540		
HB	0557,1400,1459,1489,1603,5422		
HCM	0123,0322,0424,0513,0543,0540,1659		
HEDZON	0513,0540	HEIRU	0322
HELECTRONIC (FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
HEMMERMANN	0077,0127,0391,1009		
HEXA	0204,0230	HENA	0513
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
HIFIVOX(THOMSON)			
HIGASHI	0067	HIGHLINE	0513,0540
HIGHIWA(KAISUI)	0424,0067,0236,0415,0073,1420		
HIKONA(KAISUI)	0067,0073,0236,0415,0424,1420		
HILINE	0236,0322,0415		
HINARI	0065,0080,0322,0327,0329,0363,0513,5864		
HISAWA	0073,0236,0557		
HISENSE	0083,0145,0352,0376,5481,6157,6175		
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557,1423,1608,1678,1681,1694		
HISHITO(TOSHIBA)			
HISONIX	0415		
HIT	0024		
	0037,0043,0052,0067,0082,0083,0094,0095,0119,0137,0142,0147,0160,0178,0189,0197,0209,0285,0296,0326,0329,0358,0431,0433,0473,0499,0525,0547,0554,0569,1016,1076,1259,1423,1501,1626,1644,5422,6114,6201		
HITACHI			
HITSU	0073,0513	HOME ELECTRONICS	1437
HOHER	0043,1516,1400,0170,1603,1383,1423,5422		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
HORIZONT(PHILIPS)			
HORNYPHON	0513,0540		
HOSHAI	0043,0097,0424		
HOSPITALIERE	0043	HOWELL	0043
HYD	1467,1550	HUMAX	5818
	0067,0125,0230,0236,0322,0329,0336,0415,0424,0435,0497,0513,1638,1639,1659		
HYPER			
	0025,0043,0097,0141,0170,0209,0236,0336,0557,1425,1434,5422,5864		
HYPSON			
	1449,1468,1475,1512,1554,1568,5429,5422,5437,5449,5468,5481,5824,5833,5865,5869		
HYUNDAI			
I CAN	5334	I. V.	0513
IBERIA	0428,0513	IBERVISAO	0391
ICE	0046,0057,0067,0236,0322,0415,0540		
ICS	0067,0322	IEG	0067
IMPER	0322	IJOY	6170
	0043,0057,0060,0102,0131,0170,0227,0236,0298,0374,0435,0513,1227,1619,1636,1650,1659,5468,5492,5494	IMC	0508
IMPERIAL			
INCOBE	0123,0290		
INDESIT	0107	INDIANA	0513
INGELEN	0162	INGERSOLL	0513
	0025,0043,0067,0075,0077,0115,0209,0227,0296,0332,0375,0415,0424,0513,1423,1633,1638,1639,5965		
INNO HIT			

INNO HIT	2058,4367,5407,5422		
INNOVATION	0513,0540		
INTERBUY	0125,0176,0322,0415,0505,0540		
INTERDISCOUNT	0092,0119,0242,1352,1636,5338		
INTEREACTIVE	0176,0513,0540		
INTERECORD	0133		
	0042,0046,0047,0062,0069,0079,0092,0096,0162,0302,0352,0374,0513,1617,1626,1632,1636,1654		
INTERFUNK	0513,0540		
INTERNAL	0046,0067,0077,0209,0322,0351,0435,0505,0540,0542,1657,1659		
INTERVISION	0322	INWAH	0209
INTRON	5609		
IPURE	0043,0075,0097,0125,0136,0230,0236,0322,0296,0329,0415,0513,0528,0557,1084,1126,1269,1296,1439,1400,1459,1516,1517,1525,1636,1638		
IRRADIO	0025,0067,1659		
ISKRA	0424,0513	ITAL TV	6203
ISUKAI	0067,0230,0236		
ITC	0067,0236,0322,0415,0540		
ITS	0043,0052,0062,0066,0083,0096,0108,0136,0149,0153,0162,0192,0236,0252,0290,0322,0327,0374,0390,0391,0433,0513,1423,1626,1654,1713		
ITT	5415,5422,5481,5823,5864,5877,6114,6178,6183,6190		
ITT/NOKIA	0060,0322,0354,0540	IZUMI	6182
ITV	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557,1423,1608,1678,1681,1694		
JEC (TOSHIBA)	0384,1636	JMB	0513,0540
JET POINT	0236,0435		
JOCEL	0067	JPS	0505
JOHNSON	5415,5468		
JQ	0435		
JRC	0540		
JUBILEE	0167,0316,0404,0415,0502,1470,1479,1622,1696,1697		
JVC	0300	KAIDO	0083
KABEL	0424,0513		
KAISER	0067,0073,0236,0415,0424,1420		
KAISUI	0515	KAMOSONIC	0123
KAMAR	0067,0119,0230,0322		
KAMBROOK	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
KAMP(FORMENTI)	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
KANGSLEY(FORMENTI)	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352,0375,0384,0422,0453,0513,0515,0528,0542,0547,0565,1328,1356,1382,1404,1405,1644,1657,1658,2066,4267,0043,0052,0062,0066,0083,0096,0108,0111,0136,0149,0153,0162,0192,0236,0252,0290,0322,0327,0374,0390,0391,0433,0513,1423,1626,1654,1713		
KAOSHO(SAMSUNG)	0513		
KAPSCH (ITT)	0415		
KATHREIN	0067,0111,0209,0236,0237,0238,0424,0435,0513,0516,1636		
KAWA	0067,0111,0209,0236,0237,0238,0424,0435,0513,0516,1636		
KARCHER	0025,0043,0067,0083,0111,0114,0115,0136,0170,0227		
KAWASHO(FORMENTI)			

	0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654	
KAWASHO(FORMENTI)		
KB ARISTOCRAT	0162,0391	KAYA 0322
KELCINATOR	0062	KEN 1317
KENDO	0043,0051,0073,0077,0080,0295,0300,0440,0542,1227,1636,1659,5422,5449	
KENNEDY	0108,0115,0153,0158,0222,0429	
KENNEX	0043,0097,0209,0236,0550,0552,0557,0921,1423,4367,5422	
KENSTAR	1469,5415,5484,5486,5492,5823,5833	KENYA 1327
KERION	0513,1639	KEYSMART 1400
KEYMAT	0117,0417,0480,0517,0519,0550,0553,0578,1386,1388,1391,1426,1496,1541,2395,4551,5821,5823	
KIC	0067,0237,0515	
KIMAY	0322	KINGHOME 0043
KIOTA	0322,0415,1082	
KITON	0043,0513,0540,5422	
KITT	0067,0322,0513	
KITTEN	0513	
KIYOGIN	0067,0025,0237,1174,1659	
KLARMAX	0073,0170,0209,0233,0236,0237,0295,0354,0429,0513,0541,1611	
KOBALTRONIC(NEWMAR)	0067,0123,1174,1659	
KOLSTER	0067,0077,0237,0322,0513,1174,1227,1614,1659	
KONG WAM (KAISUI)	0067,0073,0236,0415,0424,1420	
KONKA	0145,0177,0352,0415,1116,1261,1302,1420	
KONTAKT	0549	KORPEL 0513,0540
KOSMOS	0513,0540	
KOTRON	0230,0322	KRAKING 0230
KRIESLER (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705	
KRONNE	0067,0230	KTV 1500
KUBA ELECTRONIC	0067,0083,0133,0230,0391	
KUCCAI	0097	
KURO (SANYO)	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314,0363,0373,0375,1360,1423,1657,1658,1661,1668	
KYOTO	0230,0246	
L&S ELEKTRONIK	0557	
LAVA	1516,1517	
LAVIS	0025,0162,1611	
LAZER	0236	LCE 0415
LECSON	0513,0540	
LEGEND	0067,0322,0490,0513	
LENCO	0043,0077,0162,0236,0322,0329,0354,0391,0435,0513,5422,6204	
LENOIR	0043,0067,0097,0141,0322,0236,0354,0409,0424,0513,1009,1343,1394,1396,1398,1399,1400,1401,1638,1639,5871	
LEVIS AUSTRIA	0513,0540	
LEXUS	0074,0236,0322	
LEYCO	0236,0322,1646	
LG	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,0513,0529,0542,0547,0555,0557,0587,0925,1439	

LG	1459,1476,1606,1607,1614,1659,3044,4206,4207,5417,5443,5496,6113
LIFE	1435
LIFETEC	0043,0097,0209,0236,0322,0354,0513,0536,0555,0557,1638,5422,5449
LIGHTSTAR (KAISUI)	0067,0073,0236,0415,0424,1420
LINTON	0133
LLOYD'S	0067,0096,0136,0322,0415,0422,0515,1082,1626
LME (PATH CINEMA)	0025,0067,0114,0204,0230,0237,0435,1659
LOCATEL	1580,1581,1582,1583,1584
	0024,0047,0050,0176,0246,0277,0400,0402,0508,0925,1570,1637,2345,4257,4345
LOEWE	0043,0097,0374,0384,0422,0513
LOGIK	0025,0043,0067,0073,0170,0222,0230,0233,0236,0237,0295,0428,0429,0440,0528,0541,0255,1425,1449,1450,1452,1453,1454,1529,1594,1595,1619,1659
LOVE (ELBE)	
LS ELEKTRONIK	0557
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341
LTV (OCEANIC)	0043,0067,0080,0108,0153,0158,0222,0259,0295,0352,0354,0513
LUMA	
LUMATRON	0043,5422
LUXMAY	0490,0513,0540
	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178,0192,0252,0390,0431,0433,1016,1704,1713,5449
LUXOR	
LUXTRONIC	5422 LXI 0547
	0043,0067,0075,0082,0083,0123,0125,0141,0145,0153,0158,0170,0227,0277,0230,0236,0275,0329,0352,0384,0513,0529,0542,0547,0555,0557,0587,0925,1439,1459,1476,1606,1607,1614,1659,3044,4206,4207
LYOTRON (LG)	
M.D.C	1638
MACROM	0480
MADISON	0236,0540,1636
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1623,1629,1630,1631,1632,1633,1672,1705
MAGAVOX (PHILIPS)	
MAGNADYNE	0024,0025,0060,0077,0115,1009,1639,1659
MAGNAFON	0025,0067,0077,0131,0238,1126,1636,1639,1659
MAGNAVOX	0046,1623
MAGNEX	0322,1636
MAGNUM	0141,0255,0374,1415,1638
MAJESTIC	1343,1595,5437,5454,5477,5478,5479,5868,5875
MAKROSONIC	1324
MANDI	0352 MANDOR 0322
MANESTH	0052,0067,0114,0236,0322,0540,1608,1623,1654
MANHATTAN	0043,0097,0513,5422
MARANTZ	0513,0528 MARECH 0114,0513
MARK	0336,0354,0513
MASCOM	0236 MASCOT 0057
MASUDA	0236,0300,0322,0513
MATCH ITALIA	0322,0513,1636
MATSIKA	0067,0322 MATSUVIANA 0528
	0060,0065,0067,0196,0236,0269,0322,0300,0336,0351,0397,0415,0536,0549,1016,5449,5839,5864
MATSUI	
MAXDORF	0322,1084 MAXAM 0322

MAXELL	0025,0329,0424,5564,5842,5843		
MAXIMAL	1648	MB LINE	0322
MAXWELL	0025,0077,0236		
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623 1629,1630,1631,1632,1633,1672,1705		
MC MICHAEL (PHILIPS)	0322,0425,0513		
MCE	0236	MEDIASONIC	0236
MECOA	0513,0540		
MEDIATOR	0043,0097,0209,0236,0352,0552,1396,1412,1435,1455, 1638,5422,5449,5864		
MEDION	0547	MEGHA	0513
MEGATRON	0024,0025,0096,0111,0204,0237,0490,0540,1611,1659, 1667		
MELBOX (CLARIVOX)	0060,0066,0133,0136,0137,0147,0181,0209,0236,0282, 0295,0351,0354,0390,0508,0513,0588,1009,1614,1631, 1638,1644,4340,4341,5338		
MELECTRONIC	0025,0162	MEMOREX	0322
MELVOX	0067,0322,0490		
MEMPHIS	0046,0067,0236,0237,0322,0384,0515		
MERCURY	0162	METEOR	0238
MERRIT	0024,0043,0079,0097,0338,0349,0351,0402,0460,0462, 0552,1487,1499,1609,5422		
METZ	0322,0354,0513,0547,1637		
MGA	0322	MICRON	0067
MGAON	0043,0236,0295,0540		
MICROMAXX	1131	MIGROS ELECTR	0295
MICROSONIC	0236,0242,1084,1127		
MICROTEK	6176	MINATO	0513,0540
MIIA	0096,0295,0327,0351,0549,1491,1450,1609,1649,1652, 1693,1694		
MINERVA (GRUNDIG)	0549	MINOKA	0513,0540
MINERVA FRANCE	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455, 0513,1616,1663,1700		
MISTRAL (THORN)	0329		
MITRONIC	0024,0043,0047,0065,0149,0197,0230,0353,0354,0425, 0527,0547,1379,1637,1644,1661		
MITSUBISHI	0233,0298		
MITSUTI GENERAL	0105,0408,0025,0058,0068,0067,0075,5451,5605		
MIVAR	0578	MKM	0238
MKC	0043		
MKB	0077,0083,0108,0114,0133,0153,0176,0238,0513,0540, 1126		
MOBILE TV	5471,6119		
MOTION (UHER)	0083,0176,0296,0336,1296,1657,1659		
MPMAN	0238	MULTISTANDARD	0077
MTC	0025,0043,0067,0077,0125,0141,0149,0162,0178,0209, 0230,0236,0322,0336,0354,0490,0513,0545,0557,1227, 1614,1657,1696		
MULTIMAT	0083,1626,1696		
MULTITECH	0513,0540	MUSTAG	1121
MURPHY	0513,0540	MYTV	6119
MUSIKLAND	0162,0391,0547	MVISION	5488
MYSIKAD	0230,0441	NAIKO	0513,0540
NAD	0513,0540		
NAGOYA			
NAKAMURA			

	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653
NAONIS (SELECO)	
NARITA	0067,0322,0354,0547
NASSA NAGEL(ENGEL)	0230,1611
NATIONAL	0310,0518
	0149,0065,0427,1418,0472,0447,0430,1336,0237,0354,0513,5822,5822-5867
NEC	
	0024,0046,0047,0057,0060,0069,0080,0083,0114,0133,0140,0148,0167,0170,0174,0176,0178,0195,0209,0215,0227,0230,0236,0295,0300,0312,0337,0351,0352,0374,0409,0467,0508,0513,0540,0541,0555,0588,1352,1609,1629,1361,1632,1636,1638,1639,1656,5338
NECKERMANN	
NEI	0043,0230,0236,0435,0490,0541,0513,1636,1659
NEO	6114,6203
NEOVIA	1301,1383,1459,1450,1516,1517,1542,1543,1568,5468
NESCO	0125,0312,0327,0375,0440
NETSAT	0513,0540
NEUFUNK	0043
NEVIR	6120,6161,6190,6203
NEW GOLDVISION (SONOKO)	0123,0236,0322,0424,0505,0513,0557,1636
NEWMAR	0067,0123,1174,1659
NEWORLD (KAISUI)	0067,0073,0236,0415,0424,1420
NEWTECH	0067,0236,0242
NEXIUS	0588,1393,1422,1425
NEXTIER	1518
NFREN	1555,
	0025,0043,0067,0083,0114,0115,0136,0170,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654
NICAMAGIC(FORMENTI)	
NIKKAI	0067,0082,0141,0322,0329,0513
	0043,0097,0170,0322,1399,1425,1467,1550,1537,1636,5481,5609,5825,5839,5851,5872,5957,6190
NIKKEI	
NIKKEY	5483
NISSAN	0384
NIKKO	0513,0547
NOBLEX	0149,0184,0197,0354,0415,0422,1327,1661
NOBLIKO	0067,0131,0136,1126,1227
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026
NOGAMATIC(THOMSON)	
	0043,0066,0147,0162,0236,0252,0322,0390,0431,0433,0558,1423,1704,5500
NOKIA	
NORDING	0077,0131
NORDLAND	0230
	0049,0052,0062,0090,0092,0094,0095,0115,0119,0170,0229,0242,0352,0424,0455,0557,1045,1400,1422,1423,1425,1435,5415,5486,5492,5819,5823,5832,5833,5864,5871,6188,6203
NORDMENDE	
	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653
NORDTON (SELECO)	
NORDWAY	0298,1657
NORFOLK	0441
NORMEREL	0540,1630
NORM N	1636
NORTEK	0097,0141,1636
NORWAY	0298,1657
NORTON	0424
NOVAK	0513,0540
NOVA	0329
NOVATRONIC	0209,0236,0322,0329,0354,0513,1636
NUCLEAR(PRANDONI)	0077,0080,0083,0097,0115,0302,0352,0592

NUCLEAR(PRANDONI)	1126,1227		
OGENERAL	0149	OCTAL	0067
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341,5468		
OCEANIC	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
OCTAN (PHILIPS)	0236,0322,0513		
ODEON (AGASHI)	0329,1494	OK	6212
OEC ELECTRONIC	0227,0302,0513		
OKANO	1378	OLIVETTI	1379
OLIDATA	0025,0236,0237,0513,0322,0125,1659,1174,1639		
OLMAL (ALBIRAL)	1423	OLYMPIC	0424
OLYMPIA	0322,0415	ONCEAS	0060,0067
OMEGA	0236	ONIDA	0302
ONDIOLA	0077,0322,0361,0415		
ONWA	0513,0540	OR-ON	0424
OPERA	0024,0230,0236,0513,0541		
ORAVA	0067	ORBIT	0513
ORBISAT	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300,0322,0329,0352,0409,0415,0418,0447,0471,0472,0513,0555,0557,0588,1009,1251,1368,1422,1425,1623,5423,5437,5864,6177		
ORION	0046,0119,0230,0236,0269,0415,0441,0513,1059		
ORION (HUNGARY)	0513,0540		
ORLINE	0043,0097,0513		
ORMOND	0025	OSAKA (SHORAI)	0195
ORSOWE	0043,0067,0195,0513		
OSAKI	0075,0513	OSUME	0540
OSIO	0195,0300		
OTAKE	0046,1659		
OTF	5013,5023,5063		
OTHER	0025,0067,0236,0435		
OTHER LINE	0046,0047,0067,0083,0114,0125,0127,0133,0140,0162,0162,0174,0176,0177,0178,0189,0195,0197,0209,0230,0233,0236,0242,0296,0300,0310,0321,0326,0337,0351,0352,0391,0409,0415,0418,0427,0434,0435,0508,0513,0540,0555,1352,1609,1629,1632,1652,1656,1683,1684		
OTTO VERSAND	0236,0513		
OVP	0513		
PACIFIC	0067,0096,1126		
PAEL	0024,0069,0080,0083,0114,0148,0174,0176,0209,0227,0295,0409,0513,0555,0588,1609,1631,1632,1636		
PALLADIUM	0067,0302,0322,0329		
PALSONIK	0057,0067,0236,0322,0513,0540		
PANAMA	0260,0287,0310,0349,0402,0427,0518,1411,1609,1626,1659,1684,1712,2027,6116		
PANASONIC	0236,0295,0322,0536,0505,1639		
PANAVISION	0067,0123,0424,0572,1121,1131,1325,1326,1446,1447,0310		
PANAVOX	0310		
PANDA	0092		
PANORAMIC	0067,0505,0536		
PANORAMA	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
PATH MARCONI (THOMSON)			

PATH CINEMA	0025,0067,0114,0204,0230,0237,0435,1659
PCM	0114,0236,1639 PEEKTON 6161
PEACOCK	0046,0067 PERDIO 0513
PEONY	0425,0527 PERFEKT 0513
PERSHIN	0096,0204 PHILARMONIC 0060,0067
PHILBIX (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619
PHILCO	0024,0057,0060,0102,0115,0131,0149,0227,0298,0374, 0435,0513,0572,1326,1611,1636,1659
PHILIPS	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705,5338,5402,5418, 5497,5830,5834,5962,6114,6209,6210
PHILIPS (F)(PHILIPS)	0024,0042,0046,0067,0111,0119,0120,0133,0153,0302, 0352,0391,0522,0536,0540,0584,0585,0586,1317,1364, 1366,1380,1383,1415,1557,1561,1605,1607,1617,1618, 1623,1629,1630,1631,1632,1633,1672,1705
PHOENIX	0043,0046,0114,0115,0236,0238
PHONOLA (PHILIPS)	0024,0042,0046,0067,0111,0119,0120,0133,0153,0302, 0352,0391,0522,0536,0540,0584,0585,0586,1317,1364, 1366,1380,1383,1415,1557,1605,1607,1617,1618,1619, 1619,1623,1629,1630,1631,1632,1633,1672,1705
PIONEER	0095,0119,0162,0170,0302,0464,1508,5817,5820
PLANTRON	0322,0513 PLATINIUM 1509
PLASMATECH	1383,1436 PLAYDOR 0322
PLAYSONIC	0024,0123,0237,0513
POLYTRON (KATHREIN)	0513 POP 0095,0322
PORTLAND	0209,0354,0471,1638
POWERPOINT	0513,0540
PRANDONI	0025,0043,0077,0080,0083,0097,0115,0302,0352,0592, 1126,1227
PRECISION	0067,0329 PREMIER 0322,1116
PRIMA	0067,0322,0329,0505
PRINCE (PRANDONI)	0025,0043,0077,0080,0083,0097,0115,0302,0352,0592, 1126,1227
PRINCESS	0329,1425 PRINSTON 0141
PROCYON (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0532, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705
PROFESSOR	0046 PROFILE 0043
PROFEX	0131,0162,0230,0298,0435,1696
PROFILO	0025,0236,0513
PROFITRONIC	0077,0540,1636
PROLINE	0043,0295,0554,0375,0230,0418,1619,0170,0540,0513
PROSONIC	0236,0415,1638,5338,5437 PROTEK 5822,5822-5867
PROTECH	0067,0097,0230,0236,0322,0336,0374,0513,1357,1631, 1636,1638,1639,5338
PROVISION	0236,0322,0354,0390,0409,0513,0540,1320
PROTON	0547 PVISION 1489,5876
PYE (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352, 0391,0522,0536,0540,0584,0585,0586,1317,1364,1366, 1380,1383,1415,1557,1605,1607,1617,1618,1619,1623, 1629,1630,1631,1632,1633,1672,1705
PYGMY	0024,1621
QBELL	5416,5822,5822-5867,5824,5874,5963

QMEDIA	5965,6170,6184		
QUADRAL	0074		
QUADRIGA	0147,0584		
QUALCRAFT	0329		
QUADRO	0043,0074,0552,0566,0579,1112,1410,1423,1502,1503,1505,1506		
QUASAR	0025,0077,0131,0136,0196,0237,0238,0329,1126,1383		
QUEENFIDELITY (DAEWOO)	0060,0067,0209,0236,0352,0354,0361,0375,0502,0513,0545,0554,0557,1390,1412,1449,1450,1453,1601,1644		
QUELLE	0043,0046,0047,0065,0066,0067,0069,0074,0075,0077,0083,0094,0096,0097,0102,0108,0123,0125,0136,0137,0140,0147,0148,0149,0162,0164,0167,0174,0176,0184,0195,0196,0197,0215,0222,0230,0236,0242,0259,0282,0287,0290,0295,0296,0298,0300,0302,0310,0312,0322,0326,0329,0337,0339,0351,0352,0375,0390,0391,0409,0418,0427,0431,0433,0434,0471,0513,0516,0540,0552,0555,0558,0592,1126,1352,1629,1632,1636,1639,1649,1650,1652,1653,1654,1656,1657,1658,1672,1674,		
QUESTAR	0149,0197		
R. LINE	0513,0540		
RADIALVA	0236,0354,0540		
RADIOLA (PHILIPS)	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
RADIOMARELLI	0060,0024,0077,0025,0115,0230,0374,0236,1009,1639		
RADIONETTE	0066,0282,1626,1654		
RADIOSHACK	0513,0540,0547		
RADIOTONE	0107,0227,0236,0255,0322,0336,0352,0513,0536,1636,1638		
RANK / RBM	0230,0295,0435,1626,1696		
RANK ARENA	0184	REALISTIC	0547
RECOR	0074,0176,0236,0513,0540,1637		
RED STAR	0513		
REDDER	0197,0233,0237		
REDIFFUSION	0052,0162,5338		
REDO	0354	REDPOINT	0549
REFLEX	0043,0097,0236,0513,0540,1636,1639,5338		
RELISYS	1383		
RENDER	0417,0550,1400,1412,1428,1469,1551,5415,5416,5462,5823,5825		
REVOX	0176,0236,0540		
REX (SELECO)	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
RFT (BRUNS)	0024,0077,0242,0336,0363,1623,1667		
RICONH	0513,0540		
RITAR	5445	RITZ	0230
RM 2000	0043,0097,0552,1636,1639,5338		
ROADSTAR	0043,0076,0097,0141,0170,0236,0352,0528,0557,1343,1400,1423,1435,1451,1453,1469,1525,1603,1623,1636,1646,5451,5864		
ROBERTS	0327	ROBOTRON ELECTR	0024,0363
ROSNER	0067	RODEX	0513,0540
ROWA	0067,0236,0322,0528		
ROWSONIC	0067		
ROYAL	0067,0236,0322,0374,0424,0543,1305,1420		

RUKOPIR	0513,0540	RUNCO	1360
RUEFACH (LENCO)	0043,0077,0162,0236,0322,0329,0354,0391,0435,0513		
	0025,0043,0051,0055,0089,0090,0092,0094,0095,0119,0164,0181,0229,0242,0513,1603,1626,5334,5422,6114,6203,		
SABA			
SAGEM	0073,1552	SAINEL	0230
SAISHO	0065,0067,0083,0196,0237,0300,0322,0354,0418		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341		
SAITO (OCEANIC)			
SAIVOD	0043,0236,0513,0540		
SAKAI	0067		
SAKIO	0322,0354		
	0052,0075,0080,0082,0083,0137,0147,0162,0170,0178,0192,0236,0252,0390,0431,0433,1016,1659,1704,5958		
SALORA			
SAMBERS	0025,0077,0131,0237,0238,0329,1124,1126		
SAMPO	0046		
	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352,0375,0384,0422,0453,0513,0515,0528,0542,0547,0565,1328,1356,1382,1404,1405,1644,1645,1657,1658,2066,4267,5063,5419,5441,5444,5447,5451,5472,5498,6111		
SAMSUNG			
SAND	0170		
SANDRA COLOR	0025,0067		
	0052,0062,0083,0147,0162,0178,0203,0204,0251,0252,0431,0433,1626,1654,2356,4340,4341		
SANDOR (OCEANIC)			
	0149,0236,0322,0415,0424,0513,0540,0541,0557,0588,1340,1423,1469,1636,5338,5451,5437,5827,5961		
SANSUI			
	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314,0363,0373,0375,1360,1423,1657,1658,1661,1668		
SANWA (SANYO)			
	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314,0363,0373,0375,1360,1423,1657,1658,1661,1668		
SANYO			
SAR	0067,0083,0513		
SATUM (URANYA)	0025,0114,0136,0227,0236,0354,0513		
SATRONIC	0057	SAVE	0513,0540
	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300,0322,0329,0352,0409,0415,0418,0447,0471,0472,0513,0555,0557,0588,1009,1251,1368,1422,1425,1623		
SAVVILLE (ORION)			
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1561,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
SBR (PHILIPS)			
SCHAUB	5428		
	0043,0052,0062,0097,0147,0162,0178,0227,0236,0252,0322,0354,0374,0384,0400,0424,0431,0433,0435,0508,0513,0557,1393,1400,1459,1469,1475,1489,1603,1626,1636,1638,1639,1654,5609		
SCHAUB LORENZ			
	0042,0043,0067,0077,0080,0097,0115,0125,0133,0141,0153,0170,0209,0222,0230,0236,0298,0302,0329,0352,0374,0391,0415,0434,0513,0533,0592,1269,1423,1426,1496,1516,1533,1623,1636,1639,1648,1659,2395,4551,5864		
SCHNEIDER			
	0024,0042,0046,0067,0119,0120,0133,0153,0302,0352,0391,0522,0536,0540,0584,0585,0586,1317,1364,1366,1380,1383,1415,1557,1605,1607,1617,1618,1619,1623,1629,1630,1631,1632,1633,1672,1705		
SCHNEIDER (F)(PHILIPS)			
SCHWAIGER	6213		
	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636		
SCOTLAND (FORMENTI)			

SCOTLAND (FORMENTI)	1637,1639,1654
SCOTT	0114,0327,0547,1317,1638,1639,6119
SEARS (SANYO)	0024,0043,0123,0149,0184,0197,0227,0290,0312,0314,0363,0373,0375,1360,1423,1657,1658,1661,1668
SEAWAY	0043
SEDIP (PATH CINEMA)	0025,0067,0114,0204,0230,0237,0435,1659
SEELVER	0043,0513,0540
SEG	0043,0046,0057,0067,0077,0097,0123,0131,0209,0230,0236,0252,0322,0329,0363,0435,0513,0552,0555,1227,1423,1639,1659,5338
SEI (SINUDYNE)	0024,0043,0077,0115,0127,0170,0192,0195,0196,0222,0236,0295,0300,0352,0391,0409,0471,0528,0555,0581,0588,1009,1422,1425,1433,1434,1565,1622,1623,1624,1639
SEIGA (MITSUBISHI)	0024,0043,0047,0065,0149,0197,0230,0353,0354,0425,0527,0547,1379,1637,1644,1661,
SEIKO	0354
SEITECH	5871
SELECO	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653
SELECT	0043
SEMP	0337
SENTRA	0207,1608
SET	0435,0513
SHARP	0067,0149,0197,0321,1307,1421,1429,1624,1683,5432,5455,5844,5846,6114
SHINELCO	5828,5829,5841,5842,5843,5850,5851,5863,5869
SHINTOSHI	0513,0540
SHIWAN (KAISUI)	0067,0073,0236,0415,0424,1420
SHNIED	0322
SHOV	0067,0322,0415,0513
SIAREM	0024,0025,0077,0115
SICANTIC (LUXOR)	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178,0192,0252,0390,0431,0433,1016,1704,1713
SICE	1652
SIEL	0230
SIEMENS	0039,0069,0102,0148,0184,0236,0329,0351,1609,1652,
SIERA	0513,0540
SIEMSEN	5481
SIESTA	0336,1657
SILVA	0123,0149,0298,0302,0322,0329,0513
SILVER	0149,0322,0513,0540
SIMATEC (ORION)	0043,0065,0127,0141,0170,0195,0196,0236,0269,0300,0322,0329,0352,0409,0415,0418,0447,0471,0472,0513,0555,0557,0588,1009,1251,1368,1422,1425,1623
SIMTEL	0133,0322,0424
SINGER	0024,0025,0060,0067,0077,0115,0236,0415,0429,0513,0540,1227,1311,1638
SINOTECH	0322,0374,1084,1251
SINUDYNE	0024,0043,0077,0115,0127,0170,0192,0195,0196,0222,0236,0295,0300,0352,0391,0409,0471,0528,0555,0581,0588,1009,1422,1425,1433,1434,1565,1622,1623,1624,1639,5338,5851,5864,6177
SIREL	0025
SKANTIC (LUXOR)	0052,0075,0082,0083,0123,0137,0147,0162,0170,0178

SKANTIC (LUXOR)	0192,0252,0390,0431,0433,1016,1704,1713		
SKAY	0424,0513,0540	SKY LINE	0067,0410
SKY MEDIA	5819	SLAVA	0067
SLIDING	1383,1412,1426,1453,1496,1516,1543,1549,1555,1564,1569,2395,4551		
SMARAGD	0549		
SMR (MAXWELL)	0025,0077,0236		
SOLAVOX	0082,0162,1648,1654,1713		
SOMBER (CLARIVOX)	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667,		
SONICX	0236		
SONIKO	0236,0540		
SONITRON	0024,0067,0290		
SONNECLAIR	0513,0540	SONOLOR	0162,0431
SONOKO	0123,0236,0322,0424,0505,0513,0557,1636,6211		
SONORO (AGASHI)	0236,0322,0513		
SONTEC	0125,0513,1639,1657		
SONY	0065,0140,0149,0174,0215,0339,0373,0513,0785,1084,1352,1356,1470,1528,1656,1672,1674,3108,5414,5436,5452,5499,6115,6117,6179		
SOUND COLOR	0043,0141,0143,0170,0236,0322,0415,0557,1415,1603,1636,1638		
SOUND DESIGN	0547	SOUNDVISION	0077,0513
SOUNDWAVE	0074,0322,0513	SOUNDZONE	5864
SOUTHERN CROSS	1614	SOWTECH	1657
SPARKLE	0513		
SPECTRUM	0547		
SPECTRA	0236,0322,0354		
SPORT GENEXXA (FORMENTI)	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230,0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,1639,1654		
SSANGYONG (SAMSUNG)	0067,0075,0082,0170,0209,0227,0296,0312,0322,0352,0375,0384,0422,0453,0513,0515,0528,0542,0547,0565,1328,1356,1382,1404,1405,1644,1657,1658,2066,4267		
SSS (FUNAI)	0149,0230,0322,0552,0557,1558,1663		
STAG (KAISUI)	0067,0073,0236,0415,0424,1420		
STANDARD	0046,0060,0067,0114,0513		
STAR	0236,5470,5475		
STARLINE	0236		
STARLITE	0322,1638		
STARLUX	0067,0513	START	0513
STASSFURT (BRUNS)	0024,0077,0242,0336,0363,1623,1667		
STERLING	0043,0352	STENWAY	0424
STERN (SELECO)	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
STRATO	0322,0513,0540		
STRONG	1586,5467		
STT SONIG	0046	STV	0162
STVI	0067,0230	SUNIC LINE	0513
SUNKAI	0043,0073,0177,0195,0300,0447,0513,0549		
SUNNY	0415	SUNNYSKY	5453
SUNSTAR	0043,0236,0322,1354,1639		
SUNSTECH	5476,5869,6118,6119,6162	SUNWATT	0046
SUPERLA	0025,0230	SUNWOOD	0513
SUPERSONIC	0236,0322,0415,1637		

SUPERTECH	0236,0298,0415,0513,1638,1646		
SUPERTONE(PATHCINEMA)	0025,0067,0114,0204,0230,0237,0435,1659		
SUPRA	0067,0123,0322,0329,0354,0422,0547		
SUPRATECH	6167,6168,6169,6170,6173		
SUPREME	0060,0136	SWISSTEC	5819,5821
SYSLINE	0513,0540	SYDNEY	0067
SYTEL (DESMET)	0025,0043,0114,0230,0236,0246,0513,1619		
TADISTAR	0374		
TAISHO	0230		
TAKARA	0043	TALENT	1085
TALITA (CLARIVOX)	0024,0025,0096,0204,0237,0490,0540,1611,1659,1667,		
TAMASHI	1323		
TANDBERG	0024,0050,0092,0094,0195,0222,0246,0295,0349,0440,		
TANDY	0067,0080,0083		
TASTER	0046,0322	TASHIKO	0080
TATUNG	0375,0246,0067,0375,0176,0236,0254,0065,0513,0242		
TAUTO	0541	TCL	1523
TCM	0209		
TD DESIGN	0176		
TDA	0557	TEAM	0424
TEAC/TEAK	0043,0046,0047,0222,0391,0562,1269,1510,1607,1637		
	5965,6205,6206,6207		
	0043,0047,0057,0067,0097,0123,0125,0133,0141,0153,		
TEC (DUAL-TEC)	0158,0162,0170,0196,0209,0222,0230,0236,0298,0312,		
	0329,0354,0391,0409,0434,0513,0592,1400,1636,1659,		
TECCO	0067,0092		
TECHLINE	0043,0077,0097,0236,0540,0552		
	0025,0043,0067,0083,0114,0136,0170,0196,0227,0230,		
	0236,0322,0354,0435,0513,0541,0542,1619,1636,1637,		
TECHNEMA (FORMENTI)	1639,1654		
TECHNICAL	0043	TECHNILAND	0302
TECHNICS	0310,0427		
TECHNISAT	0177,0236,0555,1425,1623,4127,4214,5338		
TECHNISSON	0557,1603		
TECHNOL	0067,0176,0322,0354,0513		
TECHWOOD	0043,1423		
TECNIMAGEM	0170,1452		
TECNISON	0067		
	0043,0143,0196,0222,0236,0322,0415,0513,1343,1410,		
TECO (AMSTRAD)	1415,1423,1425,1469,1559,1638,1639		
TECSONIC	1532		
TEDELEX	0046,0067,0230,0236,0302,0490,0528,1243,1523		
TEINEL,SA	1639,1659	TEK	1127
TEKNANT	0424,0513	TEKA	1127
TEKNIKA	1614	TEKON	0384
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,		
	0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,		
TELEAVIA (THOMSON)	1445,1478,2026		
TELECHROM	0424,0513	TELECOR	0513,0540
	0051,0092,0094,0095,0102,0107,0119,0141,0164,0229,		
	0242,0378,0513,0528,0540,0566,0579,1191,1269,1301,		
TELEFUNKEN	1616,1650,5422,6114		
TELEFUSION	0513,0540		
TELEGAZI	0162,0391,0513,0540		
TELEKTRON	0077	TELEMASTER	0513

TELEMEISTER	0540	TELEPOINT	0236
TELESONIC	0513,1338	TELERENT	0176
TELESTAR	0074,0236,0302,0322,0336,0536,5864		
	1400,1426,1475,1496,1548,2395,4551,5422,5482,5489,5838,5873		
TELESYSTEM			
TELETECH	0043,0057,0097,0236,0540		
TELETON	0067,0083,0108,0149,0153,0158		
TELEVIEW	0513,0540	TELEWIRE	5485
TELRA	0513	TELEXA	0077
TEMPEST	0067,0513,0540		
TENNESSEE	0236,0540	TEMCO (SHORAI)	0195
	0043,0046,0060,0066,0067,0077,0097,0114,0195,0209,0230,0236,0238,0282,0302,0352,0354,0415,0513,0540,1632,1636,1639,1659		
TENSAI			
TESLA	0024,0046,0230,0236,0237,0352,0415,0528,5338		
TESLA SLOW (TESLA)	0024,0046,0230,0236,0237,0352,0415,0528		
TETRA			
TEVION	0043,0209,0286,0513,0557,4603,5481,5851		
TEXTET	0067	TFT	1493
THES	1526,1600,5433,5434,5437,5476,5564,5826,5847,5873,6158,6162,0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026,5836,5837		
THOMSON			
THOMSON 2100	5023	THOMSON 3004	5013
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700		
THORN			
TIME	1400,1489,1537	TLOGIC	5872
TMK	0196,0547		
TOBISHI	0067,0195,0322,0384		
TOBO	0322	TOKO (KATHREIN)	0513
TOKAI	0043,0236,0322,0435,0540		
TOKIWA (TOKAI)	0043,0236,0322,0435,0540		
TOKYO	0384,0424,1608		
TOMASHI (KAISUI)	0067,0073,0236,0415,0424,1420		
TOMITA	0067	TOPSHOW	0322
TOP VISION	0230,0238,0435,0513		
	0051,0055,0089,0090,0092,0094,0095,0096,0119,0136,0164,0181,0229,0230,0242,0455,0549,0732,1045,1435,1445,1478,2026		
TORRE (THOMSON)			
	0043,0197,0207,0259,0296,0337,0351,0386,0467,0523,0557,1423,1608,1678,1681,1694,5422,5448,5558,6112,6121		
TOSHIBA			
TOWADA	0077,0230		
	0043,0097,0170,0513,0588,1383,1425,1434,1437,1452,1453,1564,1569		
TRANS CONT.			
TRANSONIC	0322,0513,0528,0536,1607		
	0149,0230,0424,1343,1525,1549,5825,5883,5884,5885,5886,5887,5888,5958,5965,6159,6203		
TREVI			
TRIAD	0237,0513,0540	TRIDENT	0067 TRILUX 0521
TRISTAR	0046,0374		
TRIUMPH	0196,0513,0540		
TSOSHI (KAISUI)	0067,0073,0236,0415,0424,1420 TSVISION 5831,5887		
TTR	1455,		
TVSTAR	1696	TVD	0043
	0077,0083,0108,0114,0133,0153,0176,0238,0513,0540,1126,		
UHER			

ULTRAVISION	0237,0290		
ULTRAVOX	0050,0077,0354,0067,0513,0236,0409,0125,0115,0189,0024,1639		
UNDERWOOD	1391		
UNIC RADIO	0025,0067,0123,0435,1657,1659		
UNIMOR	0236,0336,0153,1657	UNITECH	5864
UNITED	0043,0141,0145,0541,0557,1400,1423,1603,1657,5415,5422,5433,5437,5454,5476,5849,5850,5864,6120		
UNITRON	0595		
	0043,0046,0047,0065,0066,0067,0069,0074,0075,0077,0083,0094,0096,0097,0102,0108,0123,0125,0136,0137,0140,0147,0148,0149,0162,0164,0167,0174,0176,0184,0195,0196,0197,0215,0222,0230,0236,0242,0259,0282,0287,0290,0295,0296,0298,0300,0302,0310,0312,0322,0326,0329,0337,0339,0351,0352,0375,0390,0391,0409,0418,0427,0431,0433,0434,0471,0513,0516,0540,0552,0555,0558,0592,1126,1352,1629,1632,1636,1639,1649,1650,1652,1653,1654,1656,1657,1658,1672,1674,1676		
UNIVERSUM (QUELLE)	1650,1652,1653,1654,1656,1657,1658,1672,1674,1676		
UNIVOX	0024,0162,0237,0540,1659		
UNK	0025,0043,0230,0236,0375,0557,1636		
URANIA (SAMBERS)	0025,0077,0131,0237,0238,0329,1124,1126		
URANYA	0025,0114,0136,0227,0236,0354,0513		
UTAX	0067		
VANGUARD	0083,0123		
VENTANA	0043		
VDTECH	6161		
	0042,0043,0057,0083,0097,0230,0236,0298,0513,0552,1423,1631,1636,1639,5338,6114		
VESTEL			
VEXA	0067,0424,0513		
VICEROY	0067,0322,0329,1082		
VIDEOLOGIC	0067,0322	VIDECON	0046
VIDEOMAC	0067,0322	VIDEON	0236
VIDEOSAT	0057,0125	VIDEOSYSTEM	0540,1636
	0043,0060,0067,0097,0119,0178,0290,0302,0374,0391,0435,0441,0540,1423,1659		
VIDEOTON			
VIDESON	0230	VIDITAL	0322
VIDIKRON	0077,0114,1661		
VISIOLA (PATH CINEMA)	0025,0067,0114,0204,0230,0237,0435,1659		
VISION 2000	0236,0322,0540,1636		
VISION MAGIC	1412	VISIONREX	0025
VISIOSAT	1599	VISTAR	0203,0431
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700		
VISTA (THORN)			
VORTEC	0145,0513,0540		
VOXSON	0024,0080,0136,0322,5609,5850		
VSM	0181	WAGNER	1654
WALKIE	0153,0295	WALKVISION	0043
	0043,0060,0067,0097,0119,0178,0290,0302,0374,0391,0435,0441,0540,1423,1659		
WALTHAM (VIDEOTON)			
	0043,0046,0080,0097,0105,0114,0115,0196,0209,0236,0322,0513,0536,0552,1636,1639,		
WATSON			
WATT RADIO	0067,0077,0115,0060,0227,0238,0298,0513,1657		
WEBER	0047,0125,0322		
WEGA VISION	0024,0149		
	0043,0057,0097,0141,0236,0302,0322,0374,0528,0540,0555,0592		
WEGAVOX			

WELLFUND	0424		
WELLINGTON	0043	WELLTECH	0557
WELTBlich	0114,0236,0513,0540,1638,1639,1646		
WESTON	0424,0435,0540		
WESTWOOD	0043,0170,0540,1338		
WHARFEDALE	0170,0540,1338		
	0067,0077,0083,0108,0114,0115,0131,0136,0153,0227,0230,0236,0295,0322,0374,0424,0435,0513,0541,1636,1639,1658,1659		
WHITE WESTINGHOUSE			
WILSON	0043		
WINDSOR	0043,0097,0513		
	0051,0217,0229,0237,0242,0254,0302,0322,0378,0455,0513,1616,1663,1700		
WINDSTAR (THORN)			
WINDY SAM	0540	WINNER	1346,
WINSTON	0043,0424,0513		
WINTERNITZ	0097,0354,0497		
WORLD TECH	0513		
WORLDVIEW	0046,0415,1636		
WOV	1450	WREMEN	0238
XCELLENT	0513,1338,1638		
XENA	0204	XONYCS	0236
XRIPTON	0074,0236,0540,1638		
YAMISHI	0424,0540	YOCAN	0540
	0067,0092,0125,0207,0230,0236,0290,0322,0354,0329,0435,0516,0540,1696		
YOKO			
YOSHITA	0513,	YOTAKA	0513
YUMATU	0074,0322,0374,0415		
ZANELA	0321,	ZAMPA	0052
	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
ZANUSSI (SELECO)			
ZAPP	5338,5414,5418,5422		
ZEM	5338,5418,5422	ZEPHIR	5464,5825
	0062,0080,0108,0153,0158,0170,0197,0222,0236,0242,0295,0352,0390,0428,0429,0435,0440,0522,0541,1181,1623,1642,1653		
ZOPPAS (SELECO)			

