



DO NOT USE THE INVERTER BEYONDITS MAXIMUM OUTPUT POWER, WHEN CONNECTED TO ANY APPLIANCE. MAKE SURE THE TOTAL STARING POWER CAPACITY DOES NOT EXCEED THE MAXIMUM OUTPUT POWER OF THE INVERTER.

IF THE TOTAL WATTS OF ELECTRICAL APPLIANCES EXCEEDS THE OUTPUT CAPACITY OF INVERTER. OR AFTER OPERATING FOR A PERIOD OF TIME. IF THE TEMPERATURE OF THE INVERTER REACHES





WISDOM FAN START : WHEN THE OUTPUT REACH 100W OR THE TEMPERATURE REACH OVER 45°C, THE FAN WELL START AUTOMATICALLY

WHEN THESE SITUATION OF OVERLOAD, OVERTEMPERTURE----ETC. HAPPEN, RED LED WILL BRIGHT TO TELL WHAT HAPPEN FOR USER THEMSELVES TO SOLVE DIFFERENT KINDS OF PROBLEMS

LOW VOLTAGE INPUT---RED LED SPARK
HIGH VOLTAGE INPUT---RED LED KEEP BRIGHT
OVERTEMPERTURE---RED LED KEEP BRIGHT
OVERLOAD---RED LED KEEP BRIGHT