

CAP1750

Quick Installation Guide

11-2015 / v1.0

Edimax Technology Co., Ltd.

No.3, Wu-Chuan 3rd Road, Wu-Gu, New Taipei City 24891, Taiwan

Email: support@edimax.com.tw

Edimax Technology Europe B.V.

Fijenhof 2, 5652 AE Eindhoven, The Netherlands

Email: support@edimax.nl

Edimax Computer Company


3350 Scott Blvd., Bldg.15 Santa Clara, CA 95054, USA

Live Tech Support: 1(800) 652-6776


Email: support@edimax.com

I. Productinformatie


I-1. Inhoud van de verpakking




1



2



3




4




5




6



7



8




9

- | | |
|----------------------------------|--|
| 1. CAP1200 Access Point | 6. Snelstartgids |
| 2. Plafond montagebeugel | 7. Ethernetkabel |
| 3. T-Rail montagekit & schroeven | 8. Voedingsadapter |
| 4. Plafondmontagekit & schroeven | 9. Plafond montagebeugel schroefmal |
| 5. CD | |

I-2. Systemvereisten

- Bestaande kabel/DSL-modem & router
- Computer met webbrowser voor de acces point configuratie

I-3. Hardware-overzicht



I-4. LED-status

| LED kleur | LED-status | Beschrijving |
|-----------|--------------------|---|
| Blauw | Aan | Het access point staat aan. |
| | Langzaam knipperen | Bezig met het upgraden van de firmware. |
| | Snel knipperen | Terugzetten naar fabrieksinstellingen. |
| Amber | Aan | Start op. |
| | Knipperend | Fout. |
| Uit | Uit | Het access point staat uit. |


I-5. Resetten

Als u problemen ondervindt met uw access point dan kunt u het apparaat terugzetten naar de standaard fabrieksinstellingen. Hiermee worden **alle** instellingen teruggezet naar standaard.

1. Druk op de resetknop op het access point en houd deze ten minste gedurende 10 seconden ingedrukt.



Wellicht moet u een speld of gelijksoortig scherp object gebruiken om de resetknop in te drukken.




2. Wacht tot het access point opnieuw is opgestart. Het access point is klaar voor de set-up als de LED **blauw** is.

II. Snelle set-up

Uw access point kan klaar voor gebruik zijn in slechts enkele minuten. Het kan fungeren als een standalone access point (AP-modus) of als een AP array (Managed AP-modus of AP Controller modus). Deze snelstartgids helpt u met het instellen van uw access point en configureert de basis instellingen.

II-1. Eerste set-up

1. Sluit het access point aan op een computer door middel van een ethernet-kabel.
2. Steek de voedingsadapter in de 12V DC voedingspoort van het access point en steek de voedingsadapter in het stopcontact met gebruik van het bijgeleverde netsnoer.



3. Wacht a.u.b. een moment totdat het access point opstart. Het access point is gereed als de LED **blauw** is.
4. Stel het IP-adres van uw computer in op **192.168.2.x**, **x** mag een nummer zijn tussen **3 – 100**. Als u niet precies weet hoe dit moet, kijk dan in de gebruikershandleiding voor meer informatie.

 **Zorg er a.u.b. voor dat er geen andere netwerkverbindingen actief zijn op uw computer (verbreek Wi-Fi verbindingen en ontkoppel ethernetkabels).**

5. Type het standaard IP-adres **192.168.2.2** van het access point in de adresbalk van een webbrows



6. U wordt gevraagd een gebruikersnaam en wachtwoord in te voeren. Voer de standaard gebruikersnaam "admin" en het standaard wachtwoord "1234" in.



7. U gaat nu naar het "Systeem informatie" scherm zoals hieronder weergegeven.

EDIMAX Pro Home | Logout | Global (English) ▼

Information Network Settings Wireless Settings Management Advanced Operation Mode

Information

- > System Information
- > Wireless Clients
- > Wireless Monitor
- > Log

System Information

| System | |
|--------------------|-----------------------|
| Model | |
| Product Name | AP801F02000000 |
| Uptime | 0 day 00:04:15 |
| System Time | 2012/01/01 00:04:32 |
| Boot from | Internal memory |
| Firmware Version | 1.3.0 |
| MAC Address | 80:1F:02:00:00:00 |
| Management VLAN ID | 1 |
| IP Address | 192.168.0.108 Refresh |
| Default Gateway | 192.168.0.1 |
| DNS | 192.168.0.1 |
| DHCP Server | 192.168.0.1 |

Wired LAN Port Settings

| Wired LAN Port | Status | VLAN Mode/ID |
|----------------|----------------------------------|-------------------|
| LAN1 | Connected (100 Mbps Full-Duplex) | Untagged Port / 1 |

- 8.** Volg nu a.u.b. de onderstaande instructies in **II-2. Basisinstellingen** om de basisinstellingen van het access point te configureren voor gebruik als standalone AP in AP-modus.

Bij gebruik van een Managed AP in een AP array, schakelt het access Point automatisch over van modus als een AP Controller wordt geconfigureerd zoals beschreven in **III. Edimax Pro NMS**.

Om het AP te gebruiken als een AP Controller (master) in een AP reeks, verwijzen wij u naar **III. Edimax Pro NMS**.

II-2. AP-modus: Basis-instellingen

De onderstaande instructies helpen u met het configureren van de basisinstellingen van het access point:

- **LAN IP-adres**
- **2.4GHz & 5GHz SSID & beveiliging**
- **Beheerdersnaam & wachtwoord**
- **Tijd & datum**



Wij raden aan dat u deze instellingen eerst configureert voordat u het access point gebruikt.

- 1.** Ga om het LAN IP-adres van het access point te wijzigen naar "**Network Settings > LAN-side IP Address (Netwerk Instellingen > LAN IP-adres)**" en u ziet het onderstaande scherm.

| LAN-side IP Address | |
|-----------------------|---------------------|
| IP Address Assignment | DHCP Client ▼ |
| IP Address | 192.168.2.2 |
| Subnet Mask | 255.255.255.0 |
| Default Gateway | From DHCP ▼ |
| Primary DNS Address | From DHCP ▼ 0.0.0.0 |
| Secondary DNS Address | From DHCP ▼ 0.0.0.0 |

- 2.** Vul de IP-adres instellingen in die u wilt gebruiken voor uw access point. U kunt afhankelijk van uw netwerkomgeving een dynamisch (DHCP) of

statisch IP-adres gebruiken. Klik op "Apply (Toepassen)" om de wijzigingen op te slaan en wacht een ogenblik tot het access point opnieuw is geladen.



Als u het IP-adres van uw access point wijzigt, moet u het nieuwe IP-adres gebruiken om de browser based configuratie-interface te gebruiken in plaats van het standaard IP 192.168.2.2.

- Om het SSID van uw access point 2.4GHz draadloze netwerk(en) te wijzigen, gaat u naar "**Wireless Setting > 2.4GHz 11bgn > Basic (Draadloze Instellingen > 2.4GHz 11bgn > Basis)**". Voer de nieuwe SSID in voor uw 2.4GHz draadloze netwerk in het "SSID1" veld en klik op "Apply (Toepassen)".



Open om meerdere 2.4GHz SSID's te gebruiken, open het drop-down menu "Enable SSID number (SSID nummer activeren)" en selecteer hoeveel SSID's u nodig hebt. Vul hierna een nieuwe SSID in het overeenkomende veld voordat u op "Apply (Toepassen)" klikt.

| 2.4GHz Basic Settings | |
|-----------------------|--|
| Wireless | <input type="radio"/> Enable <input checked="" type="radio"/> Disable |
| Band | 11b/g/n ▼ |
| Enable SSID number | 1 ▼ |
| SSID1 | <input type="text" value="3071F6_G"/> VLAN ID <input type="text" value="1"/> |
| Auto Channel | <input checked="" type="radio"/> Enable <input type="radio"/> Disable |
| Auto Channel Range | Ch 1 - 11 ▼ |
| Auto Channel Interval | One day ▼ <input type="checkbox"/> Change channel even if clients are connected |
| Channel Bandwidth | Auto ▼ |
| BSS BasicRateSet | 1,2,5,5,11 Mbps ▼ |

- Om de beveiliging van uw access point 2.4GHz draadloze netwerk(en) te configureren, gaat u naar "**Wireless Setting > 2.4GHz 11bgn > Security (Draadloze Instellingen > 2.4GHz 11bgn > Beveiliging)**". Selecteer een authenticatiemethode en vul afhankelijk van uw keuze een pre-shared sleutel of een encryptiesleutel in, klik daarna op "Apply (Toepassen)".



Specificeer in het drop-down menu welke SSID u wilt configureren als u meerdere SSID's gebruikt.

| 2.4GHz Wireless Security Settings | |
|-----------------------------------|---|
| SSID | <input type="text" value="...-3071F6_G"/> ▼ |
| Broadcast SSID | Enable ▼ |
| Wireless Client Isolation | Disable ▼ |
| Load Balancing | <input type="text" value="50"/> /50 |
| Authentication Method | No Authentication ▼ |
| Additional Authentication | No additional authentication ▼ |

5. Ga naar "**Draadloze instellingen**" > "**5GHz 11ac 11an**" en herhaal stappen **3 & 4** voor het 5GHz draadloze netwerk.
6. Ga naar "**Management > Admin (Beheer > Beheerder)**" om de beheerdersnaam en het wachtwoord van de browser based configuratie-interface te wijzigen.

| Account to Manage This Device | |
|--------------------------------------|--|
| Administrator Name | <input type="text" value="admin"/> |
| Administrator Password | <input type="password" value="....."/> (4-32 Characters) |
| | <input type="password" value="....."/> (Confirm) |
| <input type="button" value="Apply"/> | |

7. Vul de "Administrator Name (Beheerdersnaam)" en "Administrator Password (Beheerderswachtwoord)" velden in en klik op "Apply (Toepassen)".
8. Om de juiste datum en tijd voor uw access point in te stellen, gaat u naar "**Management > Date and Time (Beheer > Datum en Tijd)**".

| Date and Time Settings | |
|--|--|
| Local Time | 2012 <input type="button" value="v"/> Year Jan <input type="button" value="v"/> Month 1 <input type="button" value="v"/> Day |
| | 0 <input type="button" value="v"/> Hours 00 <input type="button" value="v"/> Minutes 00 <input type="button" value="v"/> Seconds |
| <input type="button" value="Acquire Current Time from Your PC"/> | |
| NTP Time Server | |
| Use NTP | <input type="checkbox"/> Enable |
| Server Name | <input type="text"/> |
| Update Interval | 24 <input type="text"/> hours |
| Time Zone | |
| Time Zone | (GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London <input type="button" value="v"/> |

- 9.** Stel de juiste tijd en tijdzone in voor uw access point door middel van de drop-down menu's. Het access point ondersteunt ook NTP (Network Time Protocol), dus u kunt ook de hostnaam of IP-adres van een tijdserver invoeren. Klik op "Apply (Toepassen)" als u klaar bent.




U kunt ook de "Acquire Current Time from your PC (Huidige tijd van uw PC verkrijgen)" knop gebruiken als u de tijd van uw PC wilt instellen in uw access point.

- 10.** De basis instellingen van uw access point zijn nu geconfigureerd. Zie a.u.b. **IV. Hardware Installatie** voor begeleiding voor het verbinden van uw access point met een router of PoE switch.

III. Edimax Pro NMS

De Edimax Pro Network Management Suite (NMS) ondersteunt een centraal beheer van een groep access points, tevens bekend als AP array. NMS kan worden geïnstalleerd op een access point en ondersteunt tot wel 8 Edimax Pro access points zonder dat er een extra draadloze controller nodig is. Hiermee worden kosten verlaagd en een efficiënt extern AP-beheer mogelijk gemaakt.

Edimax Pro NMS is eenvoudig te installeren. Een overzicht van het systeem is hieronder weergegeven:




Eén AP (access point) wordt aangewezen als AP Controller (master) en alle andere verbonden Edimax Pro AP's worden automatisch aangewezen als Managed AP's (slave). Met behulp van de Edimax Pro NMS kunt u alle Managed AP's configureren, monitoren en beheren (tot 8) vanuit één enkele AP Controller.


 **Controleer op de Edimax website of u de nieuwste firmware heeft voor uw Edimax Pro producten.**

1. Sluit alle AP's aan op een PoE switch die verbonden is met een gateway/router.


 **U kunt uw router als DHCP-server gebruiken of u kunt uw AP Controller later configureren als DHCP-server.**




2. Controleer of alle AP's ingeschakeld zijn en of de LED's werken.



- 3.** Wijs één AP aan als AP Controller die alle andere aangesloten AP's zal beheren (tot maximaal 8 access points).




- 4.** Sluit een computer aan op de aangewezen AP Controller met behulp van een Ethernetkabel.



5. Open een webbrowser en voer het IP-adres van de Controller in op de adresbalk. Het standaard IP-adres is **192.168.2.2**




Het IP-adres van uw computer dient zich in hetzelfde subnet te bevinden als de AP Controller. Kijk in de gebruikershandleiding voor meer hulp.



Als u het IP-adres van de AP Controller wijzigt, of als uw gateway/router een DHCP-server gebruikt, verzeker u er dan van dat u het juiste IP-adres invoert. Bekijk de instellingen van uw gateway/router.


6. Voer de gebruikersnaam en het wachtwoord in om in te loggen. De standaard gebruikersnaam en wachtwoord is **admin & 1234**.
7. U wordt doorgestuurd naar het Edimax Pro NMS Dashboard. Ga naar **“Operation Modus”** en selecteer **“AP Controllermodus”** in het dropdown-menu.



8. Klik op "Toepassen" om de instellingen op te slaan.



9. De Edimax Pro NMS wordt geleverd met een wizard om snel en eenvoudig de SSID en beveiliging in te stellen voor beheerde AP's. Klik op "Wizard" in de rechterbovenhoek om te beginnen.



10. Volg de instructies om **Stap 1 - 6** te voltooien en klik op **"Voltooien"** om de instellingen op te slaan. De wizard helpt u bij het instellen van het LAN IP-adres, 2.4GHz & 5GHz SSID en beveiliging, de administrator naam en wachtwoord, de tijd- en datuminstellingen en de beheerde AP's.

1

Before start, please power on the managed APs and plug into the same Ethernet network with this AP Controller.

This Setup Wizard will guide you through a basic procedure to configure AP Controller system.

Next >> Cancel

2

Configure IP Address

IP Address Assignment: Static IP Address

IP Address: 192.168.8.37

Subnet Mask: 255.255.255.0

Default Gateway: 192.168.8.1

Primary DNS Address: 8.8.8.8

Secondary DNS Address: 168.95.1.1

<< Back Next >> Cancel

3

Time Settings

Local Time: 2015 Year Nov Month 5 Day 14 Hours 26 Minutes 14 Seconds

Acquire Current Time from Your PC

NTP Time Server

Use NTP: Enable

Server Name: User-Defined tick.stdtime.gov.tw

Update Interval: 24 (Hours)

Time Zone: (GMT+08:00) Beijing, Hong Kong

<< Back Next >> Cancel

4

Manage This Device

Administrator Name: admin

Administrator Password: (4-32 Characters)

Administrator Password: (Confirm)

<< Back Next >> Cancel

5

Managed AP(s)

Search: Match whole words

| MAC Address | Device Name | Model | IP Address | Status |
|---|----------------|---------|---------------|-----------------------|
| <input checked="" type="checkbox"/> 74-DA-38-3E-79-10 | AP74DA383E7910 | CAP1200 | 192.168.8.102 | <input type="radio"/> |
| <input checked="" type="checkbox"/> 74-DA-38-3E-78-C0 | AP74DA383E78C0 | CAP1200 | 192.168.8.100 | <input type="radio"/> |
| <input type="checkbox"/> 74-DA-38-40-E0-E4 | | CAP1200 | | <input type="radio"/> |
| <input type="checkbox"/> 74-DA-38-30-71-D8 | | CAP300 | | <input type="radio"/> |
| <input type="checkbox"/> 74-DA-38-3E-7B-E6 | | CAP1200 | | <input type="radio"/> |
| <input type="checkbox"/> 74-DA-38-06-E1-AA | | WAP1750 | | <input type="radio"/> |
| <input type="checkbox"/> 80-1F-02-F1-95-D2 | | WAP1200 | | <input type="radio"/> |

Rescan << Back Next >> Cancel

6

Settings

SSID: Edimax 2.4GHz

Security Key: 12345678

Guest Network: Enable Disable

Guest SSID: Guest 2.4GHz

Security Key: 12345678

5GHz Settings

Clone 2.4GHz Settings

SSID: Edimax 5GHz

Security Key: 12345678

Guest Network: Enable Disable

Guest SSID: Guest 5GHz

Security Key: 12345678

<< Back Next >> Cancel

1 2 3 4 5 6 **Finish**

7 ation

Management IP

IP Address Assignment: Static IP Address
 IP Address: 192.168.2.1

Date and Time

Local Time: 2015/11/06 16:28:17
 Time Zone: (GMT+08:00) Taipei, Taiwan

Administrator Account

Administrator Name: admin

Managed AP(s)

| MAC Address | Device Name | Model | IP Address | Status |
|-------------------|----------------|---------|---------------|--------|
| 74:DA:38:27:1B:54 | AP74DA38271B54 | CAP1200 | 192.168.2.124 | |
| 74:DA:38:03:23:9C | AP74DA3803239C | WAP1750 | 192.168.2.102 | |

2.4GHz Settings


SSID: Edimax 2.4GHz
 Security Key: 12345678

Guest Network



Als één van de beheerde AP's niet gevonden wordt tijdens Stap 5, selecteer dan Beschikbare AP's en zet het beheerde AP terug naar de standaard fabrieksinstellingen. Kijk voor meer hulp in de gebruikershandleiding van het AP.

- 11.** Uw Controller AP & Beheerde AP's zouden functioneel moeten zijn. Gebruik het menu aan de bovenkant om te navigeren door de Edimax Pro NMS.



Gebruik **Dashboard, Zone Plan, NMS Monitor & NMS Instellingen** om de beheerde AP's te configureren.


Gebruik het **Lokale Netwerk & Lokale Instellingen** om uw Controller AP te configureren.



Kijk in de gebruikershandleiding voor meer informatie.

IV. Hardware-installatie

1. Verbind een router of PoE switch met de **LAN** poort van het access point door middel van een ethernetkabel.




2. Als u een router gebruikt, steek dan de voedingsadapter in de 12V DC voedingspoort van het access point en steek de voedingsadapter in een stopcontact.

3. Als u een PoE switch (Power over Ethernet) gebruikt is het niet nodig de bijgeleverde adapter te gebruiken, het access point wordt gevoed door de PoE switch.



Gebruik de adapter niet als u een PoE switch gebruikt.



COPYRIGHT

Copyright © Edimax Technology Co., Ltd. all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission from Edimax Technology Co., Ltd.

Edimax Technology Co., Ltd. makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability, or fitness for any particular purpose. Any software described in this manual is sold or licensed as is. Should the programs prove defective following their purchase, the buyer (and not this company, its distributor, or its dealer) assumes the entire cost of all necessary servicing, repair, and any incidental or consequential damages resulting from any defect in the software. Edimax Technology Co., Ltd. reserves the right to revise this publication and to make changes from time to time in the contents hereof without the obligation to notify any person of such revision or changes.

The product you have purchased and the setup screen may appear slightly different from those shown in this QIG. The software and specifications are subject to change without notice. Please visit our website www.edimax.com for updates. All brand and product names mentioned in this manual are trademarks and/or registered trademarks of their respective holders.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio technician for help.

FCC Caution

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the authority to operate equipment.

Federal Communications Commission (FCC) Radiation Exposure Statement

This equipment complies with FCC radiation exposure set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 2.5cm (1 inch) during normal operation.

Federal Communications Commission (FCC) RF Exposure Requirements

SAR compliance has been established in the laptop computer(s) configurations with PCMCIA slot on the side near the center, as tested in the application for certification, and can be used in laptop computer(s) with substantially similar physical dimensions, construction, and electrical and RF characteristics. Use in other devices such as PDAs or lap pads is not authorized. This transmitter is restricted for use with the specific antenna tested in the application for certification. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

R&TTE Compliance Statement

This equipment complies with all the requirements of DIRECTIVE 1999/5/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL of March 9, 1999 on radio equipment and telecommunication terminal equipment and the mutual recognition of their conformity (R&TTE). The R&TTE Directive repeals and replaces in the directive 98/13/EEC (Telecommunications Terminal Equipment and Satellite Earth Station Equipment) As of April 8, 2000.

Safety

This equipment is designed with the utmost care for the safety of those who install and use it. However, special attention must be paid to the dangers of electric shock and static electricity when working with electrical equipment. All guidelines of this and of the computer manufacture must therefore be allowed at all times to ensure the safe use of the equipment.

EU Countries Intended for Use

The ETSI version of this device is intended for home and office use in Austria, Belgium, Bulgaria, Cyprus, Czech, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Turkey, and United Kingdom. The ETSI version of this device is also authorized for use in EFTA member states: Iceland, Liechtenstein, Norway, and Switzerland.

EU Countries Not Intended for Use

None

EU Declaration of Conformity

- English:** This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Français:** Cet équipement est conforme aux exigences essentielles et autres dispositions de la directive 1995/5/CE, 2009/125/CE, 2006/95/CE, 2011/65/CE.
- Čeština:** Toto zařízení je v souladu se základními požadavky a ostatními příslušnými ustanoveními směrnic 1995/5/ES, 2009/125/ES, 2006/95/ES, 2011/65/ES.
- Polški:** Urządzenie jest zgodne z ogólnymi wymaganiami oraz szczególnymi warunkami określonymi Dyrektywą UE 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC..
- Română:** Acest echipament este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 1995/5/CE, 2009/125/CE, 2006/95/CE, 2011/65/CE.
- Русский:** Это оборудование соответствует основным требованиям и положениям Директивы 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Magyar:** Ez a berendezés megfelel az alapvető követelményeknek és más vonatkozó irányelveknek (1995/5/EK, 2009/125/EK, 2006/95/EK, 2011/65/EK).
- Türkçe:** Bu cihaz 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC direktifleri zorunlu istekler ve diğer hükümlerle ile uyumludur.
- Українська:** Обладнання відповідає вимогам і умовам директиви 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Slovenčina:** Toto zariadenie spĺňa základné požiadavky a ďalšie príslušné ustanovenia smerníc 1995/5/ES, 2009/125/ES, 2006/95/ES, 2011/65/ES.
- Deutsch:** Dieses Gerät erfüllt die Voraussetzungen gemäß den Richtlinien 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Español:** El presente equipo cumple los requisitos esenciales de la Directiva 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Italiano:** Questo apparecchio è conforme ai requisiti essenziali e alle altre disposizioni applicabili della Direttiva 1995/5/CE, 2009/125/CE, 2006/95/CE, 2011/65/CE.
- Nederlands:** Dit apparaat voldoet aan de essentiële eisen en andere van toepassing zijnde bepalingen van richtlijn 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC..
- Português:** Este equipamento cumpre os requisitos essenciais da Directiva 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Norsk:** Dette utstyret er i samsvar med de viktigste kravene og andre relevante regler i Direktiv 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- Svenska:** Denna utrustning är i överensstämmelse med de väsentliga kraven och övriga relevanta bestämmelser i direktiv 1995/5/EG, 2009/125/EG, 2006/95/EG, 2011/65/EG.
- Dansk:** Dette udstyr er i overensstemmelse med de væsentligste krav og andre relevante forordninger i direktiv 1995/5/EC, 2009/125/EC, 2006/95/EC, 2011/65/EC.
- suomen kieli:** Tämä laite täyttää direktiivien 1995/5/EY, 2009/125/EY, 2006/95/EY, 2011/65/EY oleelliset vaatimukset ja muut asiaankuuluvat määräykset.

FOR USE IN 



WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Declaration of Conformity

We, Edimax Technology Co., Ltd., declare under our sole responsibility, that the equipment described below complies with the requirements of the European R&TTE directives.

Equipment: AC1750 Ceiling Mount Access Point
Model No.: CAP1750

The following European standards for essential requirements have been followed:

Directives 1999/5/EC

Spectrum : ETSI EN 300 328 V1.9.1 (2015-02);
EMC : EN 301 489-1 V1.9.2 (2011-09);
EN301 489-17 V2.2.1(2012-09);
EN 301 893 V1.8.1(2015-03);
Safety (LVD) : IEC 60950-1:2005 (2nd Edition)+Am 1:2009+Am 2:2013
EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013

Recommendation 1999/5/EC

EMF : EN 62311:2008

Directives 2006/95/EC

Safety (LVD) : IEC 60950-1:2005 (2nd Edition)+Am 1:2009+Am 2:2013
EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013

Edimax Technology Co., Ltd.
No. 3, Wu Chuan 3rd Road,
Wu-Ku Industrial Park,
New Taipei City, Taiwan



Date of Signature: Dec, 2015

Signature:

Printed Name:

Albert Chang

Title:

Director

Edimax Technology Co., Ltd.

Notice According to GNU General Public License Version 2

This product includes software that is subject to the GNU General Public License version 2. The program is free software and distributed without any warranty of the author. We offer, valid for at least three years, to give you, for a charge no more than the costs of physically performing source distribution, a complete machine-readable copy of the corresponding source code.

Das Produkt beinhaltet Software, die den Bedingungen der GNU/GPL-Version 2 unterliegt. Das Programm ist eine sog. „Free Software“, der Autor stellt das Programm ohne irgendeine Gewährleistungen zur Verfügung. Wir bieten Ihnen für einen Zeitraum von drei Jahren an, eine vollständige maschinenlesbare Kopie des Quelltextes der Programme zur Verfügung zu stellen – zu nicht höheren Kosten als denen, die durch den physikalischen Kopiervorgang anfallen.

GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA
Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software—to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Lesser General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will individually obtain patent licenses, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep

intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES



EDIMAX
NETWORKING PEOPLE TOGETHER

The logo features the word "EDIMAX" in a bold, white, sans-serif font. A small red dot is positioned above the letter "I". Below the brand name, the tagline "NETWORKING PEOPLE TOGETHER" is written in a smaller, white, all-caps sans-serif font. The entire logo is centered on a black horizontal band. This band is decorated with a repeating pattern of white line-art icons, including a handshake, musical notes, a smiley face, a game controller, and various network symbols. The background of the page is white, with a thin, solid purple horizontal bar at the very bottom.